

From lab to production, providing a window into the process

Transducer Cleaning Tool Kit



Important

The cleaning tool must be used when the polymer is in a semi - molten state. Care must be taken not to exceed a torque rating of 100 inch - pounds during scraping so as not to damage the cutting edges of the tool. These cutting edges are manufactured from hardened tool steel and will not wear if reasonable care is exercised. It is strongly recommended that a high temperature lubricant be applied to the tap and the threads of the guide sleeve and gauge plug to prevent seizing.

Description

erification

The cleaning tool kit was designed by Dynisco for use in removing excess plastic from mounting holes for pressure and temperature transducers. Installation of transducers into improperly cleaned or sized holes is one of the major causes of damage to these instruments. With this kit, the .312" tip diameter hole, the 45 degree seating surface, and the .451" hole can be cleaned. The kit includes a gauging plug which is used to verify that the hole has been correctly machined and cleaned. M10 and M18 cleaning kits also available.

Profitability

Material Analysis

Sustainability


Suggested Procedure

Step 1: Clean threads of hole with four - fluted bottoming tap until threads are clean.

Step 2: Thread the guide sleeve/cleaning drill into the hole. Finger tight is sufficient. In a clockwise motion, push and turn cleaning drill so that the residue is scraped from critical surfaces. Do not rock tool back and forth. Remove tool and clean off residue. Reinsert tool and scrape again. Continue this operation until tool is clean when removed.


Step 3: Apply Dykem blueing on gauge plug surfaces below thread. Insert the gauge plug into the hole and rotate until surface binding is encountered. Remove and inspect. Blueing should only be scraped off 45 degree sealing chamfer. If blueing is removed from other surfaces, then mounting hole is not clean or has not been machined properly.

Ordering Guide for Transducer Cleaning Tool Kit



Gauge plug for PT435A, PT467E, and PT465XL ordered separately, refer to P/N435901.

Dimensions





www.dynisco.com

DSMDT4X2FSIL2 Rev: 1216

Dynisco

38 Forge Parkway Franklin, MA 02038 USA

Hotline 1-800-Dynisco www.dynisco.com Phone +1 508 541 9400 Fax +1 508 541 6206 Email infoinst@dynisco.com

Refer to www.dynisco.com for access to Operator Manual and other support documentation.

All dimensions are inches (mm) unless otherwise specified. ©2016. Dynisco reserves the right to make changes without notice.

Dynisco Europe, GmbH Pfaffemstr. 21

74078 Hellbronn

Germany

Phone +49 7131 297 0 +49 7131 297 166 Fax Email dyniscoeurope@dynisco.com

Dynisco Shanghai Building 7A, No. 568 Longpan Rd Malu Jiading, 201801 China

+86 21 34074072-819 Phone Toll Free +86 400 728 9117 +86 21 34074025

Fax