

From lab to production, providing a window into the process

SPX Product Family Smart Melt Pressure Transmitters

Sustainability

Intrinsically safe and Explosion-proof Pressure transmitters with integrated amplifier For use in hazardous environments

Material Analysis

Profitability

Operating Manual







DYNISCO SPX QUICK START CARD

This Quick Start Setup guide can be used by experienced instrumentation technicians to configure the Transmitter using the Zero and Span actuators or via the optional HART Communications. For more detailed information please consult the complete manual before operating. The Quick Start procedure with HART is designed for users already familiar with the use of the HART Communicator and loop powered instrumentation.

QUICK START Using Zero Actuator

- Insure the mounting hole is clear of any frozen polymer or debris and is machined to the proper dimensions. Apply a quality high temperature Anti-Seize lubricant to the snout tip threads. For flanged configuration units, apply Anti-Seize to mounting bolt threads and use proper button seal gasket and install on transducer snout. Install unit into the process connection. (Do NOT torque transmitter into the hole at this time!) Allow time for the transmitter snout temperature to equalize to the process temperature. This will help eliminate thread galling and ease removal later. There should be NO pressure applied at this time.
- 2. Connect power to the transmitter. For conduit output configurations, Red wire is Sig+/Exc +, Black wire is Sig-/Exc-, Green wire is Ground. For a 6 or 8 pin connector version, Pin A is Sig+/Exc+ and pin B is Sig-/Exc-. Insure proper loop supply voltage is applied to transmitter.
- 3. After temperatures have equalized, apply proper torque as described in Section 5.2 of the Manual and tighten transmitter into mounting hole.
- 4. Perform Zero Function

a. SPX 2XXX/4XXX/5XXX (Pushbutton)

- ATTENTION
- Do not remove seal screw when the circuit is live in a hazardous area
- Remove zero pushbutton seal screw
- Using a 2mm or smaller Allen key, depress the pushbutton for a ½ second
- Release pushbutton for a ½ second
- Depress the pushbutton again for a ½ second and release
- b. SPX 3XXX (Hall Effect Switch)
 - Unthread Zero screw from endplate
 - Depress screw
 - Release screw
 - Depress screw
 - Release screw
 - Restore screw in endplate

Note: The screw must be threaded into the endplate for normal operation. Failing to do so will cause the device to go into failsafe.



5. Verify loop output is zero (4 mA).

QUICK START UTILIZING HART COMMUNICATOR

- 1. Follow Steps 1 through 3 from Quick Start Using Zero Actuator.
- 2. Connect Communicator to the loop. If unsure on how to do this, refer to "Connecting the HART Handheld Communicator" (Figure 6-1).
- 3. Power on HART Communicator. See HART Command tree on the following page for reference.
- 4. From the Main Menu:
 - a. Enter Tag (Quick Key 1, 3, 1)
 - b. Set Pressure Units (Quick Key 1, 3, 2), if required
 - c. Set URV (Quick Key 1, 3, 3, 2) if output turndown (rescaling), is required
 - d. Perform Zero Trim (Quick Key 1, 2, 5, 1, 3, 1)
- 5. Verify loop output is zero (4mA).
- 6. Remove HART Communicator from loop.



From lab to production, providing a window into the process







fication

in Mell

NOTE: Above is the Menu Tree for the latest Device Descriptor. For units with software revision < 100 refer to Appendix 2 for appropriate Menu Tree.





1	GENERAL	6
2	NOTES ON SAFETY	11
3	TECHNICAL DATA	21
4	TRANSPORT/DELIVERY	266
5	INSTALLATION	277
6	COMMISSIONING	355
7	MAINTENANCE	490
8	TROUBLESHOOTING	512
9	ACCESSORIES	52
10	APPROVALS/CERTIFICATES	534
11	APPENDIX 1 - DEFAULT VALUES	700
12	APPENDIX 2 – Menu Tree (Software Revision < 100)	711
13	APPENDIX 3 – Oil Fill Offset	722
14	OUTLINE DRAWINGS	73
15	DYNISCO CONTACT INFORMATION	

Profitability

Material Analysis

Sustainability

rification



1 GENERAL

1.1 IMPORTANT INFORMATION

This manual applies to the SPX melt pressure product family. The SPX industrial pressure family is covered in a separate manual. This manual must be kept near the equipment in a readily and immediately accessible location at all times. The content of this manual must be read, understood and followed in its entirety. This applies in particular to the notes on safety. Following the safety instructions will help to prevent accidents, defects and malfunctions.

DYNISCO will not be held liable for any injury, loss or damage resulting from failure to follow the instructions in this manual.

If the product malfunctions, in spite of having followed the operating instructions, please contact customer service from our website:

www.dynisco.com/contact

1.2 COPYRIGHT

Copyright law requires that this manual be used for intended purposes only.

It is strictly forbidden to allow reproduction of any kind "in whole or in part" to persons outside of Dynisco, without approval from Dynisco.

HART is a registered trademark of HART Communication Foundation.



1.3 **EXPLANATION OF ICONS**

The manual uses icons to indicate information pertaining to safety:

ATTENTION	Risk of destruction or damage to equipment, machines or installations
\wedge	General danger to life or limb
	Specific danger to life or limb
CE	CE EMC specific requirements
(Ex)	ATEX Intrinsic Safety specific requirements
FIM Approvals	FM Approvals Explosion proof specific requirements
۲. ۲. ۲. ۲.	CSA Explosion proof specific requirements
NEPSI	NEPSI Intrinsic Safety or Explosion proof specific requirements
TOVRheinland CENTIFIED	Related to Safety Integrity and Performance Level Applications

The safety instructions are provided again in the individual sections of the manual.



1.4 ABBREVIATIONS

The following abbreviations are used:

BSI	Best Straight Line
DDL	
עט	Device Descriptor
EEPROM	Electrically Erasable Programmable Read Only Memory
FS	Full Scale
HART	Highway Addressable Remote Transducer
LRV	Lower Range Value
РТ	Pressure Transmitter
PV	Primary Variable (Pressure)
RTD	Resistance Temperature Detector (A very accurate temperature sensor)
SV	Secondary Variable (Electronics Temperature)
TV	Tertiary Variable (Snout Temperature)
URV	Upper Range Value
Watchdog	An internal monitor for the electronics

1.5 NAMING CONVENTION

SPX	Melt Smart Pressure Transmitters (SPX 2xxx/3xxx/4xxx/5xxx Series)
SPX-L	Melt Smart Pressure Transmitters with Linearity Correction (SPX 5xxx series)
SPX-T	Melt Smart Pressure Transmitters with Linearity Correction and Process
	Temperature Compensation (SPX 3xxx series)



1.6 TRANSMITTER PRINCIPLES OF OPERATION

The mechanical system (filled assembly) consists of a lower diaphragm, a filled capillary tube, and an upper diaphragm with a strain gage. The filled assembly transmits pressure from the process to the strain gage diaphragm where it is converted to an electrical signal. The filled assembly isolates the electronics from the high process temperatures.

The lower diaphragm is the surface in contact with the media being measured. This diaphragm can be made from a choice of materials. The standard material is heat-treated 15-5 stainless steel with Dymax[™] coating. This has average corrosion and abrasion resistance and is similar to 17-4 stainless steel. Other materials are also available including Hastelloy C-276 which has excellent corrosion resistant properties (but is not good for abrasion). For other materials please consult the factory.

Behind the lower diaphragm is a capillary tube filled with a liquid (typically Hg, mercury) to the upper diaphragm. As the process pressure deflects the lower diaphragm, the fill is displaced through the capillary tube to deflect the upper diaphragm. Other fill liquids are available, please consult the factory.

The upper diaphragm has a strain gage element in the configuration of a Wheatstone Bridge. The deflection of the upper diaphragm causes a change in the resistance of the strain gage and hence a change in the balance of the bridge. The amount of imbalance is directly proportional to the applied pressure. This completes the translation of pressure applied to the lower diaphragm into a usable electrical signal.



Figure 1-1 Functioning Principle of the SPX 3xxx Filled Assembly



The low level output signal from the bridge is amplified via an instrumentation amp circuit. The amplified signal then goes to the input of the analog-to-digital (A/D) converter.

Once the microprocessor has the converted voltage input from the A/D converter, the digital signal is sent to a digital-to-analog (D/A) converter which modulates the current of the unit's power supply between 4 and 20 mA for an output current proportional to the applied pressure.

Profitability

Material Analysis

Sustainability

There is also a resistance temperature detector (RTD) in the tip of the sensor (SPX 3XXX Models only). This sensor is used to measure the temperature of the snout tip to improve accuracy by compensating for snout temperature effects on the pressure measurement. The temperature sensed by this RTD can be accessed digitally via HART or via an optional 4-20 mA temperature output. 4 mA and 20 mA correspond to 0 and 400 Celsius, respectively.

An alternative 3 wire RTD temperature output option is available. The 3 wire RTD temperature output comes from a second RTD located in the snout tip (SPX 3XXX Models only, not available with 4-20 mA temperature output). The RTD is a 100 ohm RTD with an alpha of 0.00385 ohms/°C.

1.7 CORRECT USE

When using an SPX as a safety component in accordance with the EC Machine Directive, Annex IIc, the equipment manufacturer must take any necessary precautions to ensure that malfunction of the PT cannot cause damage or injury.



For installation in explosive gas atmospheres the device must be installed in accordance with European installation guidelines EN 60079-14. For category 1 (zone 0) installations, over voltage protection of the electrical connections shall be in accordance to EN 60079-14.

When planning machinery and using one of the units from the SPX Family, follow the safety and accident prevention regulations that apply to your application, such as:

- EN 60204, Electrical equipment in machines
- EN 12100, Machine safety, general design guidelines
- DIN 57 100 Part 410, Protection against electric shock
- EN 60079-0 Explosive atmospheres General Requirements
- EN 60079-11 Explosive atmospheres Intrinsically Safe Apparatus
- EN 60079-26 Special Requirements for EPL Ga

1.8 USER'S OBLIGATIONS

The operator or owner of the larger overall system, e.g. a machine, is responsible for following the safety and accident prevention regulations that apply to the specific application.



2 NOTES ON SAFETY



2.1 GENERAL DANGER TO LIFE OR LIMB

The operator or owner of the larger overall system is responsible for following the safety and accident prevention regulations that apply to the specific application.

DYNISCO will not be held liable for any injury, loss or damage resulting from failure to follow the instructions in this manual.

The SPX is an ESD sensitive component. Electrostatic discharge may damage the SPX. Take ESD precautions.

Electrical shock can result in death or serious injury. Avoid contact with the leads and terminals. High voltage that may be present on leads can cause electrical shock.

Mounting and electrical connection of the PT must be done by specialists with EMC training, following all applicable regulations, and in **pressure-less**, **voltage-free**, **intrinsically safe** condition with the **machine switched off. The machine must be secured against being switched back on!**

Deviation of the supply voltage from the value given in the technical specifications, or reverse polarity, can damage the pressure transmitter and cause malfunctions that can pose a risk of explosion.

Several configurations of the SPX are designed and approved for use in hazardous classified areas. **Units** intended for installation in these areas must bear the applicable approval agency label.

The SPX can be used in media temperatures up to +400°C (based on configuration). If the pressure transmitter is used in other applications, the safety and accident prevention regulations specific to that application must be followed. Ambient temperature for the electronics housing is +85°C maximum in areas that are not classified as hazardous.



Higher temperatures can result in damage and malfunction. Do not install the pressure transmitter in places where these temperatures are exceeded.

Profitability

Material Analysis

Sustainability

Before connecting a HART handheld communicator in an explosive atmosphere, make sure the instruments in the loop are installed in accordance with intrinsically safe or non-incendive field wiring practices.



2.2 SPECIFIC DANGER TO LIFE OR LIMB

Toxic Hazard!

The SPX typically contains a very small amount of mercury, Hg (approx. 0.00322 in³ for a 6/18 configuration), as its transmission medium. If the diaphragm is damaged, mercury may escape. Never transport or store the SPX without the protective cap. Remove the cap shortly before installation.

If mercury is inhaled or swallowed, seek medical attention immediately!

Mercury is hazardous waste and must be disposed of in accordance with applicable laws. **DYNISCO** will accept defective PT's. If mercury escapes, use airtight packaging!

CE

2.3 CE EMC SPECIFIC REQUIREMENTS

Connect the shield of the connecting cable on both sides, making sure it conducts with full and continuous contact.

When introducing the connecting cable into an EMC compliant switch cabinet, for example, connect the shield correctly (cable gland, conducting, full contact, and continuous) to the conductive housing or route it via a built-in cable connector that is also connected to the conductive housing. Connect unused cable cores or free cable ends correctly to the cable shield on both sides.





2.4 ATEX INTRINSIC SAFETY APPROVAL SPECIFIC REQUIREMENTS

The housing of the SPX shall be connected reliably to the local equipotential bonding system. The housing is electrically bonded to the process equipment through the process connection.

The installation of the SPX must be in accordance with European installation guidelines EN 60079-10.

For category 1 (zone 0) installations, over voltage protection of the electrical connections shall be in accordance to EN 60079-14.

For category 1 (Zone 0) installations, care must be taken to avoid the danger of ignition due to electrostatic discharges (ESD). The chance for static build up on the cable surface during normal conditions of use, maintenance and cleaning must be eliminated. Install the cable in an appropriate conduit or use some other cable reliable installation technique to avoid static electricity at the cable surface.

The free length of the cable must be below 5 cm. If metallic conduits are used they need to be grounded. If nonmetallic conduits are used they need to be antistatic (< 1G Ohm/cm^2).

For application as category-1-equipment the connecting cable shall be equipped with a suitable conductive coating (Rsurface < 10^9 ohms) to avoid possible electrostatic charge.

Those variants of the SPX that include the material aluminum shall be installed in such a way that sparking as a result of impact or friction between aluminum and steel is excluded. Impact or friction between aluminum and stainless steel is allowed if the existence of rust particles can be excluded.

After installation before operating the device the user must check that the complete installation and wiring is intrinsically safe. Special care must be taken to insure that the power source is a certified apparatus.

If the transmitter is installed in hazardous areas, only passive devices like switches or resistors may be connected between the RCAL+ and RCAL- signals. Connection of any active electronic circuits or voltage or current sources is not allowed.

In non-conduit units with the secondary 4-20mA option proper creepage and clearance distances must be maintained between the mating connector and cabling per EN/IEC 60079-11. Proper creepage and clearance distances are maintained using Dynisco SPX-T ATEX Intrinsically Safe mating connector cable assemblies;

PT style connector cable assys - 50 ft cable - p/n 641002, 100 ft cable - 641004 PC style connector cable assys - 50 ft cable - p/n 641012, 100 ft cable - 641014

Additional ATEX Intrinsically Safe approval specific requirements are provided on the EC Type Examination certificate, Dynisco drawing number 975161, located in section 10.2 of this manual. The



medium temperature (T_{med}) listed in the EC Type Examination certificate is defined as the temperature of the pressure transmission fluid below the measuring diaphragm (See Figure 1-1). This temperature can be verified by measuring the surface temperature at the base of the electronics housing.

Maximum allowed pressure range of each SPX by pressure range model code:

Pressure Range					
XX					
Code	PSI	Bar	Kgf/cm ²	MPa	KPa
01	1	0.07	0.07	0.007	7
02	2	0.14	0.14	0.014	14
03	3	0.2	0.2	0.02	20
04	4	0.27	0.27	0.027	27
05	5	0.35	0.35	0.035	35
06	10	0.7	0.7	0.07	70
07	15	1	1	0.1	100
08	25	1.75	1.75	0.175	175
09	50	3.5	3.5	0.35	350
10	75	5	5	0.5	500
11	100	7	7	0.7	700
12	150	10	10	1	1000
13	250	17.5	17.5	1.75	1750
14	500	35	35	3.5	3500
15	750	50	50	5	5000
16	1000	70	70	7	7000
17	1500	100	100	10	10000
18	2000	140	140	14	14000
19	2500	175	175	17.5	17500
20	3000	200	200	20	20000
21	5000	350	350	35	35000
22	7500	500	500	50	50000
23	10000	700	700	70	70000
24	15000	1000	1000	100	100000
25	20000	1400	1400	140	140000
26	25000	1750	1750	175	175000
27	30000	2000	2000	200	200000
33	200	14	14	1.4	1400



 Image: Section 2.5
 FM EXPLOSION PROOF APPROVAL SPECIFIC REQUIREMENTS

 Installation shall comply with the relevant requirements of the National Electrical Code (ANSI/NFPA 70)

Installation shall comply with the latest edition of the instruction manual. The latest edition of the instruction manual is available for download from the Dynisco website:

www.dynisco.com

Replacement with non-factory components may adversely affect the safe use of the systems.

Additional SPX-T FM Explosionproof Approval specific installation requirements are provided on the SPX-T FM Explosionproof Control drawing, Dynisco drawing number 000610, Figure 5-1 of this manual.

Also see section 10 of this manual (<u>Approvals and Certificates</u>) for FM certificates of compliances that list hazardous location limitations and approved model code configurations.

For SPX units that are explosion-proof approved the power supply rating is 13-30 Vdc.

- 1) Do not remove the transmitter push-button seal screws in explosive environments when the circuit is live (applicable to all models except SPX-T).
- 2) Transmitter push-button seal screws must be fully engaged to meet Explosion-proof requirements (applicable to all models except SPX-T).





2.6 CSA EXPLOSIONPROOF APPROVAL SPECIFIC REQUIREMENTS

SPX-T CSA Explosionproof Approval specific installation requirements are provided on the SPX-T CSA Explosionproof Control drawing, Dynisco drawing number 000611, Figure 5-2 of this manual.

Contact factory for CSA certificates of compliances that list hazardous location limitations and approved model code configurations.

SPX-T units are Explosionproof with Intrinsically Safe Output, Exia

Maximum non-hazardous voltage not to exceed 250V.

For SPX units the power supply rating is 13-30 Vdc.

- 1) Do not remove the transmitter push-button seal screws in explosive environments when the circuit is live (applicable to all models except SPX-T).
- 2) Transmitter push-button seal screws must be fully engaged to meet Explosion-proof requirements (applicable to all models except SPX-T).

See pressure range table in section 2.4 for maximum allowed pressure range of each SPX by pressure range model code:



providing a window into the process



2.7 NEPSI INTRINSIC SAFETY REQUIREMENTS

一、产品安全使用特殊条件

产品防爆合格证号后缀"X"代表产品安全使用有特殊条件:

1. 产品外壳含有轻金属,用于0区时需注意防止由于冲击或摩擦产生的点燃危险。

Profitability

Material Analysis

Sustainability

2. 产品外壳含非金属,使用时须防止产生静电火花,只能用湿布清理。

二、产品使用注意事项

1. 产品温度组别与使用环境温度范围和介质温度范围之间关系为:

温度组别	Т6	Τ4
使用环境温度范围	-20°C~+50°C	-20°C~+85°C
介质温度范围	-20°C~+60°C	-20°C~+85°C

2. 本安电气参数:

最高输入电压	最大输入电流	最大输入功率	最大内部	等效参数
$U_{i}(V)$	$I_{i}(mA)$	$P_{i}(W)$	$C_i(nF)$	$L_i(\mu H)$
30	100	0.75	4.5	40

3. 该产品必须与已通过防爆认证的关联设备配套共同组成本安防爆系统方可使用于爆炸性 气体环境。其系统接线必须同时遵守本产品和所配关联设备的使用说明书要求,接线端子不得接 错。

4. 用户不得自行更换该产品的零部件,应会同产品制造商共同解决运行中出现的故障,以 杜绝损坏现象的发生。

5. 产品的安装、使用和维护应同时遵守产品使用说明书、GB3836.13-2013"爆炸性环境 第13部分:设备的修理、检修、修复和改造"、GB3836.15-2000"爆炸性气体环境用电气设备 第15部分:危险场所电气安装(煤矿除外)"、GB3836.16-2006"爆炸性气体环境用电气设备 第16部分:电气装置的检查和维护(煤矿除外)"、GB3836.18-2010"爆炸性环境 第18部分:本质安全系统"和GB50257-1996

"电气装置安装工程爆炸和火灾危险环境电力装置施工及验收规范"的有关规定。





NEPSI EXPLOSIONPROOF SPECIFIC REQUIREMENTS

二、产品安全使用特殊条件

产品防爆合格证号后缀"X"代表产品安全使用有特殊条件:

- 1. 产品外壳含非金属,使用时须防止产生静电火花,只能用湿布清理。
- 2. 涉及隔爆结合面的维修须联系产品制造商。
- 二、产品使用注意事项
 - 1. 产品温度组别与使用环境温度范围和介质温度范围之间关系为:

温度组别	使用环境温度
T6	$-20^{\circ}\mathrm{C} \sim +60^{\circ}\mathrm{C}$
T5	$-20^{\circ}\text{C} \sim +85^{\circ}\text{C}$

2. 用户在使用时应将产品外壳可靠接地。

3. 安装现场应不存在对产品外壳有腐蚀作用的有害气体。

4. 用户不得自行更换该产品的零部件,应会同产品制造商共同解决运行中出现的故障,以 杜绝损坏现象的发生。

5. 产品的安装、使用和维护应同时遵守产品使用说明书、GB3836.13-2013 "爆炸性环境 第13部分:设备的修理、检修、修复和改造"、GB3836.15-2000 "爆炸性气体环境用电气设备 第15部分:危险场所电气安装(煤矿除外)"、GB3836.16-2006 "爆炸性气体环境用电气设备 第16部分:电气装置的检查和维护(煤矿除外)"和GB50257-

1996 "电气装置安装工程爆炸和火灾危险环境电力装置施工及验收规范"的有关规定。



From lab to production, providing a window into the process

2.9 SAFETY INTEGRITY AND PERFORMANCE LEVEL APPLICATIONS



Product Safety Functional

User's obligations

www.luv.com ID 0600000000

Safety

The operator or owner of the larger overall system, e.g. a machine, is responsible for following the safety and accident prevention regulations that apply to the specific application.

Profitability

Material Analysis

Sustainability

Intended Use

See Certificate in section 10.5

Safety Function

See Certificate in section 10.5

For units with the optional monitoring channel (Guardian Series, Option Code = GCxxx):

Under normal operating conditions the relay contacts are closed. In the event that a failure is detected the relay contacts open. Detectable failures include:

- 1) Loss of Power
- 2) Open Gage
- 3) Input over a predefined (customer selectable at time of order) threshold

The Guardian Series transducer has been designed to provide a protective measure. This has been done by the avoidance and control of systematic and random failures.

This product will:

Measure the pressure and provide a safety relay output. Since this is being used to perform a protective measure, this sensor should only be used for monitoring the pressure and not controlling the process. Best practices declare that safety and control must be independent from each other.

The Guardian Series transducer detects many hardware failures including an open or short in the measuring gage and if there is an overpressure condition. If any of these failures occur, the output relay will open. It is the user's responsibility to connect this relay to the system in such a way that when this relay opens, it brings the system to a safe state.

This fault state is not latched. It is up to the user to latch this error if desired.

Recommended practices



This Guardian Series transducer must be installed in such a way that the opening of the output relay will bring the system to a safe state. In this safe state the instrument that is monitoring the pressure should be left operational.

Profitability

Material Analysis

Sustainability

This error indication is not latched. If it is necessary to latch the error until it is manually reset, this is the user's responsibility.

At startup and on a periodic basis the safety system should be tested to ensure proper operation. This will require applying a pressure to the Guardian Series transducer that is over the safe level but less than the maximum pressure. Verify that the protective measure is initiated to take the machine to a safe operating condition.

Use of qualified personnel

The product may only be assembled, installed, configured, commissioned, operated and maintained by persons with proven skills. Persons with proven skills are suitably experienced to operate devices, systems, plant and machinery in accordance with the general standards and guidelines for safety technology.

It is the user's responsibility only to employ personnel who:

- Are familiar with the basic regulations concerning health and safety and accident prevention
- Have read and understood the safety guidelines given in this description
- Have a good knowledge of the generic and specialist standards applicable to the specific application

Connecting Safety Relay

Relay specs: Maximum switching voltage: 200Vdc; Maximum switching current: 0.5A

Device pinout



CONNE	CONNECTOR WIRING mA-HART		
PIN	FUNCTION		
A	POWER +		
B	SIGNAL -		
C	POWER -		
D	N/C		
E	RCAL +		
F	RCAL -		
G	RELAY CONTACT		
н	RELAY CONTACT		



3 TECHNICAL DATA

3.1 MODEL CODE BREAKDOWN

The exact meanings of the letter/digit combinations are given in the corresponding sections of this Chapter.



3.2 ORDERING EXAMPLE



Note(s):

- 1) Review section 3.4 Performance Characteristics for accuracy definition and details.
- 2) Review "Notes on Safety" (Chapter 2) before installation in Hazardous locations.
- 3) Accuracy can be affected with choice of diaphragm and coating.
- 4) Certain models are not available in some configurations.
- 5) For other process connections please consult factory.
- 6) Please see the appropriate figure in section 5.8 for dimensions of your specific flange.
- 7) For other mounting flanges/process connections not listed please consult factory.
- 8) Other approved ranges may exist, please consult factory.
- 9) Other lengths available, please consult factory.
- 10) Transmitters are available with certain approved option codes. Please consult factory for list of approved options.

3.3 SAFETY SPECIFICATIONS

Please see "Notes on Safety" (Chapter 2.)



3.4 PERFORMANCE CHARACTERISTICS

3.15.1 ACCURACY

Accuracy is defined as combined error expressed as a percentage of full scale (% F.S.) output based on the following standard configurations/conditions:

- 1) Mercury Filled Capillary $\leq 36''$
- 2) Dymax Coated 15-5 SST Process Diaphragm
- 3) Best Straight Line % F.S. as per ISA-37.3
- 4) +20°C ambient electronics

*Consult factory for availability of NaK filled units or other non-standard configurations.

	Snout		Accuracy
Model	Temp	Range	(% of FS)
		< 1500 PSI	+/- 0.75
	20°C -	1500 PSI	+/- 0.50
SPX 32XX	300°C	≥ 1500 PSI	+/- 0.25
		< 1500 PSI	+/- 0.50
	20°C -	1500 PSI	+/- 0.25
SPX 33XX	300°C	≥1500 PSI	+/- 0.15
		< 1500 PSI	+/- 0.50
SPX 2242/2243	20°C	≥ 1500 PSI	+/- 0.25
SPX 2241	20°C	Entire Range	+/- 1.0
		< 500 PSI	+/- 0.50
SPX 2244	20°C	≥500 PSI	+/- 0.25
SPX 229X	20°C	Entire Range	+/- 0.50
		< 1500 PSI	+/- 0.50
SPX 4222/4232/4352	20°C	≥ 1500 PSI	+/- 0.25
SPX 4622/4672/4502	20°C	Entire Range	+/- 0.50
SPX 5342	20°C	Entire Range	+/- 0.20
SPX 5343	20°C	Entire Range	+/- 0.20
SPX5344	20°C	Entire Range	+/- 0.20
SPX5390	20°C	Entire Range	+/- 0.20
SPX5391	20°C	Entire Range	+/- 0.20
SPX5392	20°C	Entire Range	+/- 0.20

3.15.2 RESOLUTION

±0.035% full scale or better



3.15.3 REPEATABILITY

± 0.10% of full scale

3.15.4 OVERLOAD PRESSURE (MAX PRESSURE WITHOUT INVALIDATING SPECIFIED ACCURACY)

Model	Pressure
SPX 2242/2243/5342/5343	2 X FSP or 35,000 PSI, whichever is less
SPX 2241/2244/5344	2 X FSP or 15,000 PSI, whichever is less
SPX 229X/539X	2 x FSP
SPX 4222/4232/4352/4622/4672	2 x FSP or 35,000 PSI, whichever is less
SPX 4502	3 x FSP
SPX 3X42/3X43/3X9X	1.5 x FSP

Profitability

Material Analysis

Sustainability

3.15.5 BURST PRESSURE

Model	Pressure
SPX 2XXX/4XXX/5XXX	6 x FSP or 45,000 PSI, whichever is less
SPX 3XXX	Greater than 2 x FSP

3.15.6 FREQUENCY RESPONSE

20 Hz [-3db]

3.15.7 RESPONSE TIME

50 mS

3.5 ELECTRICAL DATA

Configuration	4-arm Wheatstone bridge strain gauge with internal amplifier
Output Signal	2-wire 4 - 20 mA
Saturation Levels	3.8 mA and 20.5 mA
Fail Safe Levels	3.6 mA for Low Level > 21mA for High Level
Current Consumption Supply Voltage	< 25 mA 13 - 30 VDC for PTB ATEX IS and FM XP approved models 13 - 32 VDC for non-approved models



Note: Transmitter incorporates overvoltage protection and reverse polarity protection and will not operate if inputs are reversed.



250 ohms minimum for HART communication

3.6 TEMPERATURE INFLUENCE

ELECTRONICS HOUSING

SPX 3XXX

Sense Resistor Load Line

Operating Temperature Range	-29°C to +85°C			
Compensated Temperature Range (SPX 2XXX/4XXX/5X)	XX) -20°C to +65°C			
Compensated Temperature Range (SPX 3XXX)	20°C to +85°C			
Zero Shift due to temperature change on electronics housing				
SPX 2XXX/4XXX/5XXX SPX 3XXX	0.01% FS/°F max. (0.02% FS/°C max.) Included in accuracy specification			
Span shift due to temperature change on electronics housing				
SPX 2XXX/4XXX/5XXX	0.01% FS/°F max. (0.02% FS/°C max.)			

Included in accuracy specification



PROCESS CONNECTION

Zero shift due to temperature change on the diaphragm

SPX 2242/2243/4xxx/5xxx (except SPX 4502)

15 PSI/100/°F typical 2 BAR/100/°C typical

SPX 2241/2244/229X/4502

1 PSI/100°F typical (from 75°F to 450°F) 2 PSI/100°F typical (from 450°F to 600°F) 0.07 BAR/38°C typical (from 24°C to 232°C) 0.14 BAR/38°C typical (from 232°C to 315°C)

SPX 3XXX

Included in accuracy specification

3.7 EMC REQUIREMENTS

The SPX Conforms to CE in accordance with EMC directive. See Declaration of Conformity for more details.

3.8 MATERIALS

Standard Diaphragm	15-5PH Mat. No. 1.4545 Various proprietary coatings
Standard Stem (Snout)	17-4PH Mat. No. 517400

Please note other diaphragm and stem materials may be substituted.

3.9 TORQUE

See section 5.2

3.10 ENVIRONMENTAL PROTECTION TO ANSI/IEC-60529 & ANSI/NEMA-250

SPX with sealed conduit to IP67, NEMA 4X

3.11 WEIGHT

The weight varies depending on product configuration. Average weight range is 1 to 5 pounds.

3.12 DIMENSIONS

The dimensions vary based on product configuration. Contact Dynisco if product dimensions are required.



4 TRANSPORT/DELIVERY



Toxic hazard!

The SPX contains a small amount of mercury (Hg) as its standard transmission medium. If the diaphragm is damaged, mercury may escape. For alternate (non-Hg) transmission mediums please consult factory.





If mercury is inhaled or swallowed, seek medical attention immediately.

Mercury is hazardous waste and must be disposed of in accordance with applicable laws. **DYNISCO** will accept defective SPXs.

If mercury escapes, use airtight packaging!

ATTENTION	The SPX is an ESD sensitive component. Electrostatic discharge may damage the SPX.	Take ESD
	precautions.	

4.1 TRANSPORT/PACKING/TRANSPORT DAMAGE

- Do not let the SPX be damaged by other items during transit
- Use only the original packaging
- Report transport damage to DYNISCO immediately in writing

4.2 STORAGE

- Store the SPX in original packaging only
- Protect against dust and moisture

4.3 SCOPE OF DELIVERY

- SPX with diaphragm protection cap
- Fastening clip (transmitter with flexible stem only)
- Calibration sheet
- Operating manual with declaration of conformity



INSTALLATION

NOTES:

2. Follow all Notes on Safety in Section 2 during installation.

5.1 GENERAL MOUNTING INFORMATION

Do not remove the protective cap on the SPX until ready to install.

Before mounting the SPX, check mounting hole carefully. The SPX must only be mounted in holes that satisfy the requirements below. A hole that does not satisfy these requirements can damage the Transmitter.

Profitability

Material Analysis

Sustainability

Insure the mounting hole is clear of any frozen polymer or debris and is machined to the proper dimensions.

For threaded SPX transmitters coat the threads with a high temperature anti-seize grease or a suitable parting agent, this will help prevent the SPX snout from sticking permanently in the mounting hole. For flanged configuration units, apply Anti-Seize to mounting bolt threads. Use proper Buttonseal gasket and install on transducer tip.

Install unit into the process connection (Do NOT torque transmitter into the hole at this time!). Allow time for the transmitter snout temperature to equalize to the process temperature. This will help eliminate thread galling and ease removal later. There should be NO pressure applied at this time.

Always use a torque wrench applied to the designated hexagon collar or mounting bolts while screwing the transmitter in and out. Do not apply the tool to the housing or housing/sensor connection.

After temperatures have equalized, apply proper torque as described in Section 5.2 of the Manual and tighten transmitter into mounting hole.

After the correct torque has been applied units with flexible capillary require the electronics to be mounted away from the process heat using mounting hardware, P/N 200941.

Connect power to the transmitter. For conduit output configuration, Red wire is Sig+/Exc +, Black wire is Sig-/Exc-, Green wire is Ground. For a 6 or 8 pin connector version, Pin A is Sig+/Exc+ and pin B is Sig-/Exc-. Insure proper loop supply voltage is applied to transmitter.

Make sure that the medium is in molten condition during transmitter removal. Removing the transmitter while the medium is in solidified condition can damage the sensor diaphragm.



providing a window into the process

When removing the SPX, carefully clean the diaphragm of the transmitter with a soft cloth while the medium is still malleable.

Always remove the SPX prior to cleaning the machine with abrasives or steel wire brushes. Also, do not clean the SPX with hard objects, such as a screwdriver, a wire brush, etc. This will possibly damage the transmitter.

Before reinstalling the SPX, ensure that the mounting hole is free from hardened plastic. A mounting hole cleaning tool kit is available to aid in removing of the material. (Dynisco Part Number 200100 for ½-20, 200101 for M18 and 200102 for M10 ports.) A gauge plug to check the hole is included in this kit.



The SPX is an ESD sensitive component. Electrostatic discharge may damage the PT. Take ESD precautions.



Mounting and electrical connection of the SPX must be done by specialists with EMC training, following all applicable regulations, and in **pressure less**, **voltage-free**, **intrinsically safe condition with the machine switched off**.



TTENTION

The machine must be secured against being switched back on!

The most common causes of transducer damage are: installation in improperly machined or plugged mounting holes and cold starts. The tip of the transducer consists of a stainless steel diaphragm that must be protected from severe abrasives, dents and scores.



Burn Hazard! The SPX must be removed with the melt in the molten condition. The SPX can be very hot when removed. WEAR PROTECTIVE GLOVES!



Profitabili

Material Analysis

Sustainability

Careful attention should be paid to correctly machine the mounting port. Failure to use the recommended mounting port may result in erroneous pressure measurement, difficult transducer removal, premature sensor failure, process fluid leaks, and personnel hazard. In applications involving high temperature operation and/or repeated thermal cycling a good high quality anti-seize compound should be applied to the threaded surfaces.

5.2 MOUNTING HOLE TORQUE

Model	SPX 2242 SPX 3X42 SPX 4222/4622/4352/4672 SPX 5342	SPX 2243 SPX 3X43 SPX 4232 SPX 5343	SPX 2241/2244/2290/2291 SPX 3X9X SPX 4502 SPX 539X/5344	SPX2292
Torque	Max. 56.5 Nm	Max. 5.6 Nm	Max. 39.5 Nm	Max. 108.5Nm
Spec	(500 inch-lbf.)	(50 inch-lbf.)	(350 inch-lbf.)	(80 ft-lbf.)



5.3 MOUNTING HOLE DIMENSIONS

Please contact Dynisco if mounting hole dimensions are required.

5.4 MOUNTING HOLE PRESSURE TRANSMITTER

Dynisco offers a set of mounting hole-machining tools with all the necessary drills, taps, and reamers for the Dynisco standard ½-20 UNF-2A and M18 and M10 mounting holes used in high temperature and plastics processing applications (Dynisco Part Numbers 200925, 200105 and 901949 respectively). Detailed instructions are sent with the machining kits. Copies of the instructions are available from Dynisco upon request.

When machining the hole pay careful attention to the concentricity between the threads and the 0.312/ 0.314 diameter. Since the pressure seal is on the 45° seating surface, this surface should be examined for good finish, free from burrs, etc.

It is general good practice to check the mounting hole before installing the transducer. One procedure is to coat a gauge plug (Dynisco Part Number 200908 for the 1/2 -20 standard port, 435901 for the short tip $\frac{1}{2} - 20$ version, 200960 for the M18), with Dykem machine bluing on surfaces below the thread. Insert the gauge plug into the mounting hole and rotate until surface binding is encountered. Remove and inspect. Bluing should only be scraped off of the 45° sealing chamfer. If bluing has been removed from other surfaces, the mounting hole has not been machined properly.



5.5 INSTALLING THE FLANGED PRESSURE TRANSMITTER

Note that the pressure seal on flange mounted units is made at the lower o-ring or gasket, not the flange.

See section 5.2 for recommended mounting torques.

Recommended mounting torques to crush appropriate gasket material:

Pressure Range	Gasket	Part Number	<u>Torque</u>
3,000 psi	Aluminum	494602	15 ft/lbs
10,000 psi	Parkerized Carbon Steel	634001	60 ft/lbs
10,000 psi	Hastelloy	634002	60 ft/lbs
10,000 psi	303 Stainless Steel	634004	60 ft/lbs

5.6 ELECTRICAL CONNECTION

The SPX has 4-20 mA output. The transmitter power supply and output are supplied over the same pair of wires.

It is recommended that you use twisted, shielded cables as connecting wires.

Observe National Electric Code and national regulations for applications in hazardous areas.

Do not lay connecting cables in the direct vicinity of cables carrying higher voltage or used to switch inductive or capacitive loads.

For FM approved SPX 3XXX Explosionproof installations, install in accordance with controlled drawing 000610 (Figure 5-1).



For CSA approved SPX 3XXX Explosionproof installations, install in accordance with controlled drawing 000611 (Figure 5-2).



5.7 CONNECTION ASSIGNMENTS

The device must be connected to a certified power supply. Each unit will include a primary 4-20mA output. The unit may also have one of the options listed in the table below. See section 2.9 for wiring details of units with GCxxx option code.

		Connection Type			
Signal	Terminal Description	Conduit-Lead Wire Color	6-Pin	8-Pin	
	PWR+/SIG+	Red	А	А	
Primary 4-20mA	PWR-/SIG-	Black	В	В	
	CASE	Green	-	-	
		Options			
Optional RCAL	RCAL+	Orange	F	E	
Only	RCAL-	Blue	E	D	
SPX 3XXX Only Options					
Ontional RCAL	RCAL+	Orange	-	E	
with Secondary A	RCAL-	Blue	-	D	
20mA only	2nd PWR+/SIG+	Violet	-	G	
	2nd PWR-/SIG-	Yellow	-	Н	
Optional	2nd PWR+/SIG+	Violet	-	G	
Secondary 4- 20mA only	2nd PWR-/SIG-	Yellow	-	Н	
Ontional Dual PTD	RTD (-)	White	-	D	
	RTD (+)	Grey	-	E	
Unity	RTD (+)	Brown	-	F	
Color Code					
SPX					
SPX 3XXX ONLY					

Note: The Optional Dual RTD option (TA) is a second RTD in the snout tip that is brought to the connector. The RTD is a 100 Ohm RTD with an alpha of 0.00385 Ohms/°C.



If the transmitter is installed in hazardous areas, only passive devices like switches or resistors may be connected between the RCAL+ and RCAL- signals. Connection of any active electronic circuits or voltage or current source is not allowed.



From lab to production, providing a window into the process



Verfication

to Mercial

Profitability

Material Analysis

1118

Sustainability



Figure 5-1 Electrical Configuration for FM Approved Explosionproof SPX 3XXX Installations





Figure 5-2 Electrical Configuration for CSA Approved Explosionproof SPX 3XXX Installations

5.8 FLANGE CONFIGURATIONS

Please contact Dynisco if flange configurations are required.



6 COMMISSIONING

There are two ways of commissioning the SPX transmitters. This can be done by utilizing the ZERO and SPAN actuators or by HART Communications via a communicator connected to the pressure loop.

If the SPX is equipped with the optional HART communications, it is not necessary to access the zero/span actuators on the sensor.

If the transmitter is not equipped with HART then the zero/span actuators must be utilized. However, Sections 6.3 through 6.8 and 6.11 may be skipped.

6.1 WHY A TRANSMITTER MUST BE REZEROED

The transmitter output must be nulled at zero pressure after installation when the machine has stabilized at operating temperature. This is easy to understand why when considering the mechanical properties of the sensor.

As described in section 1.5, a fill fluid transmits the process pressure from the sensor tip of the transmitter (at process temperature) to the electronics housing (at ambient temperature). As the transmitter sensing tip is brought from ambient to process temperature, the fill fluid expands and increases the amount of deflection on the sensing diaphragm. This creates a positive pressure reading, as if a small pressure was actually applied, even with zero pressure on the system. Even with the advanced temperature correction performed by the SPX 3XXX, there is a slight residual temperature offset so rezero may be beneficial.



Also, depending on the orientation of the sensor, the weight of the fluid will have an effect on the sensing diaphragm. The weight of the fluid will either increase the deflection of the diaphragm as if a small pressure is applied or may pull on the diaphragm as if pressure was pulling away from the sensor (a negative reading).

Profitability

Material Analysis

Sustainability

There are some other effects that may affect the zero as well, such as torque, side loading, etc. For more information contact Dynisco.

All of these effects can be compensated for by setting the transmitter zero after the machine has stabilized at operating temperature.

6.2 UTILIZING THE ZERO AND SPAN ACTUATORS

When the transmitter output needs to be corrected due to mounting location and temperature shift the zero actuator can be used (if a HART Communicator is not available.) Please wait until the process has been brought to operating temperature before zeroing. The zero procedure is only recommended after the process temperature has stabilized and the SPX electronics housing has been permanently installed.

When the actuator is depressed in a certain sequence, the output will be corrected to reflect 4 mA. This is done by the transmitter electronics automatically by adjusting the LRV and URV settings simultaneously to the offset required to obtain 4 mA. Normally a Zero calibration is all that is required after installation since the Transmitter span has been calibrated at the factory. In the event the Full Scale output is not correct when checked against a calibrated pressure source or dead weight tester, the transmitter span can be adjusted via the Span actuator. This is performed by applying a known calibrated full scale pressure to the transmitter and depressing the Span actuator in a certain sequence. When complete, the transmitter electronics will have adjusted the URV to correct to output to equal 20 mA.

ATTENTION The span actuator should never be used to set the URV without zeroing the PT with the zero actuator first.

If for some reason the calibration is incorrect and the user wishes to revert back to the Factory Calibration, a procedure can be performed to revert the calibration back to factory state. Refer to "Resetting to Factory Default Settings" in this Chapter.

6.2.1 ZERO AND SPAN PROCEDURE

- 1. Connect Power Supply to SPX signal leads with 250 ohm load and milliamp meter in series with loop.
- 2. If commissioning on the bench with a dead weight tester or calibrated pressure source, ensure pressure connection is free of leaks.
- 3. Apply power to the SPX transmitter and observe loop current with zero pressure applied. It should be 4 mA. If other than 4 mA proceed to step 4.
- 4. Perform Zero Function






- ATTENTION
- i. Do not remove seal screw when the circuit is live in a hazardous area.
- ii. Remove zero pushbutton seal screw.
- iii. Using a 2mm or smaller Allen key, depress the pushbutton for a ½ second.

Sustainability

Profitability

Material Analysis

- iv. Release pushbutton for a ½ second.
- v. Depress the pushbutton again for a ½ second and release.
- b. SPX 3XXX (Hall Effect Switch)
 - i. Unthread Zero screw from endplate
 - ii. Depress screw
 - iii. Release screw
 - iv. Depress screw
 - v. Release screw
 - vi. Restore screw in endplate

Note: The screw must be threaded into the endplate for normal operation. Failing to do so will cause the device to go into failsafe.

The available pressure is now adopted as the new lower range value

______Steps past this point are not part of a normal bench setup and should only be performed by qualified ATTENTION individuals, as the SPX is highly stable and has been factory calibrated with highly accurate pressure generators. This function should only be performed on such equipment.

- 5. Apply Full Scale pressure and verify output is 20 mA. If output is other than 20 mA, perform Local Span adjustment:
 - a. SPX 2XXX/4XXX/5XXX (Pushbutton)
 - i. Do not remove seal screw when the circuit is live in a hazardous area.
 - ii. Remove span pushbutton seal screw.
 - iii. Using a 2mm or smaller Allen key, depress the pushbutton for a ¹/₂ second.
 - iv. Release pushbutton for a 1/2 second.
 - v. Depress the pushbutton again for a ½ second and release.

ATTENTION

b. SPX 3XXX (Hall Effect Switch)

- i. Unthread Span screw from endplate
- ii. Depress screw
- iii. Release screw
- iv. Depress screw
- v. Release screw
- vi. Restore screw in endplate

Note: The screw must be threaded into the endplate for normal operation. Failing to do so will cause the device to go into failsafe.



The available pressure is now adopted as the new upper range value.

6.3 UTILIZING THE HART COMMUNICATIONS

The zero procedure is only recommended after the process temperature has stabilized and the SPX electronics housing has been permanently installed. When the zero trim function is selected (HART Quick key 1,2,5,1,3,1) the output will be corrected to reflect zero pressure. This is done by the transmitter electronics automatically by adjusting digital PV to zero and analog output will be 4 mA. Normally a Zero Trim is all that is required after installation since the Transmitter span has been calibrated at the factory.

In the event the Full Scale output is not correct when checked against a calibrated pressure source or dead weight tester, the Transmitter span can be adjusted by performing the Sensor Trim function. This is performed by first applying Zero Pressure and selecting Lower Sensor Trim (HART Quick Key 1, 2, 5, 1, 3, 2) and following the prompts on the HART Communicator. When complete, apply a known calibrated full scale pressure to the Transmitter and selecting Upper Sensor Trim (HART Quick Key 1, 2, 5, 1, 3, 3) and follow the prompts on the HART Communicator. When complete, the transmitter electronics will have adjusted the digital PV to correct to full scale output.

ATTENTION Never perform upper sensor trim without performing lower sensor trim first.



6.3.2 CONNECTING THE HART HANDHELD COMMUNICATOR



In hazardous areas, refer to the handheld communicator instruction manual for instructions for HART Communicator to function properly.

ATTENTION

ON A minimum of 250 Ohms resistance must be present in the loop.

The HART Communicator does not measure loop current directly.

The HART Communicator can interface with the SPX anywhere along the 4 - 20 mA cable as shown in the following figure.



Figure 6-1 HART Communicator Interface

6.3.3 PROCEDURE

1. Connect Power Supply and HART Communicator per the above diagram.



2. If commissioning on the bench with a dead weight tester or calibrated pressure source, insure pressure connection is free of leaks.

Profitability

Material Analysis

Sustainability

- 3. Apply power to the SPX transmitter and turn on the HART Communicator by pressing the ON/OFF key. The LCD display should show [SPX-T or SPX depending on model] in the upper left corner. If this is not present, consult the Troubleshooting section of this manual.
- 4. Set PV Units (Fast Key 1,3,2) to appropriate pressure unit. (e.g. psi, Bar, kgf/cm2, MPa)
- 5. Set Tag (Fast Key 1,3,1).
- 6. If transmitter output needs to be re-ranged, set the appropriate LRV (Fast Key 4,1) and URV (Fast Key 4,2)
 - Note: URV cannot be turned down below the PV Minimum span (Fast Key 1,4,1,5)
- 7. Set Lower Trim (Fast Key 1,2,5,1,3,1)
- 8. Verify SPX transmitter output. Zero pressure output should read 4 mA.

ATTENTION

Steps past this point are not part of a normal bench setup and should only be performed by qualified individuals, as the SPX is highly stable and has been factory calibrated with highly accurate pressure generators. This function should only be performed on such equipment.

- 9. Next, using calibrated pressure source, apply pressure equal to value set in URV in step 6. Output should equal 20 mA. If output does not equal 20 mA proceed to step 10.
- 10. To calibrate full scale output, first apply pressure equal to full scale pressure of unit. Next perform Upper Sensor Trim (Fast Key 1,2,5,1,3,2). Output should now equal full scale pressure.
- 11. If Transmitter Output Damping is required, set PV Damping (Fast Key 1,3,5) to the appropriate value.
- 12. Press the left arrow key until the HART Communicator is off-line then turn the power off.

The SPX pressure transmitter is now ready to be installed in the process.

6.4 SPX ANALOG OUTPUT

The SPX has a 4-20 mA output proportional to pressure for normal operating conditions. However, unlike a traditional sensor, the SPX performs self-diagnostic routines continually during operation. If a special condition is detected, the transmitter drives its analog output outside the normal saturation values to indicate that investigation is necessary. (This condition is called fail-safe mode alarm.) The conditions detected by the self-diagnostic routines (and the corresponding effect on the analog output) are listed later in this section.

When a special condition is detected, the SPX goes into fail-safe mode and the transmitter output goes high, by default. However, using a HART communicator, the transmitter can also be configured to drive its output low or to freeze the output where it was just before the fail-safe was detected. The actual analog output levels are indicated below.

A low alarm (3.6 mA) is possible but not recommended because HART communications are not guaranteed until the cause of the alarm is removed.



Using the HART communicator, the specific condition that triggered the fail-safe mode alarm can be read for diagnostic purposes. (See Status in the HART menu tree.)

In a fail-safe condition the PV is not affected and can still be read using the handheld HART communicator. For process related fail-safe conditions, the transmitter will remain in the alarm state until the source of error disappears. If certain electronics errors are detected, the fail-safe condition will latch until a reset is performed by either cycling the power or through a software command.

NAMUR Compliant Saturation and Alarm Values

	<u>4 - 20 mA Sa</u>	turation	า	4	l - 2	0 mA	Alarm	<u>1</u>
Low	3.8 mA			3	8.6 r	nA		
High	20.5 mA			>	>21	mA		
	 		-				~	

You can alter the actual transmitter mA output values by performing an analog output trim using the HART Communicator.

When a transmitter is in an alarm condition, the analog output displayed by the handheld indicates the alarm value of the analog output – NOT the value the transmitter would have, if the sensor had not detected the failure.

Special Conditions and the Corresponding Analog Output

Condition	Alarm Value (fail safe)
EEPROM failure detected	Set to configured fail safe mode
Cold start	Set to fail safe mode low
Pressure above upper limit	Unchanged
Pressure below lower limit	Unchanged
Electronics temp above upper limit	Unchanged
Electronics temp above lower limit	Unchanged
Strain gage open detected	Set to configured fail safe mode
Analog output saturated	Unchanged
Watchdog error detected	Unchanged
Zero/Span Actuator stuck	Set to configured fail safe mode
Low voltage detected	Unchanged
Outside URV or LRV	Unchanged
Rcal simulation on	Unchanged

6.5 ALARM & SATURATION VALVES BURST MODE

No special requirements are defined for the burst mode.

6.6 ALARM & SATURATION VALUES IN MULTIDROP MODE

If the device is in multidrop mode, the NAMUR levels are no longer achievable. Instead the fail safe condition is indicated by the field device status and the additional diagnostics.



6.7 SPX TRANSMITTER FUNCTIONS VIA HART

Zero Trim (1,2,5,1,3,1)

Digital Correction to zero which affects the digital output. This differs from Lower Sensor Trim in that zero trim is ONLY performed at zero pressure.

Lower Sensor Trim (1,2,5,1,3,2)

Digital Correction to zero which affects the digital output. This differs from Zero Trim in that Lower Sensor Trim can be performed at pressures above zero.

Note: This must be performed before Upper Sensor Trim. Only perform this function with a known calibrated pressure source.

Upper Sensor Trim (1,2,5,1,3,3)

Digital correction to Full Scale which affect digital output. Note: Lower Sensor Trim must be performed before Upper Sensor Trim. Only perform this function with a known calibrated pressure source.

Digital to Analog trim (1,2,5,1,2)

This is used to match the digital representation of the analog output with its actual analog loop current. Note: This should only be performed with a known Calibrated Current (mA) meter.

Reranging

ATTENTION

The SPX allows for the 4 mA and 20 mA points (LRV and URV respectively) to be adjusted so that output resolution can be improved. A Re-range or "Turndown" ratio of 6:1 is possible. Accuracy specifications remain dependent upon the Full Sensor Range without any turndown applied. Three methods of Re-ranging the SPX Transmitter are outlined below.

Note: If pressure applied to the transmitter is not in the range of the 6:1 turndown ratio, the transmitter will reject the Span attempt. This will be indicated by the output not adjusting to 20 mA after a few attempts using the Span Actuator.

Reranging TV (SPX 3XXX) with "TB" option only

On a SPX 3XXX with the TB option, there is a second 4-20mA output that is proportional to the snout temperature. By default the TV LRV and TV URV are set to 0 and 400C respectively. The secondary 4-20mA output can be reranged by changing TV LRV and TV URV.

Reranging via Zero/Span Actuators

When HART Communication is not used, LRV and URV values are entered by applying zero pressure to the SPX 3XXX and "Rezeroing" by:

- a. SPX 2XXX/4XXX/5XXX (Pushbutton)
 - i. Do not remove seal screw when the circuit is live in a hazardous area.
 - ii. Remove zero pushbutton seal screw.
 - iii. Using a 2mm or smaller Allen key, depress the pushbutton for a ½ second.
 - iv. Release pushbutton for a ½ second.



v. Depress the pushbutton again for a ½ second and release.

Profitability

Material Analysis

Sustainability

- b. SPX 3XXX (Hall Effect Switch)
 - i. Unthread Zero screw from endplate
 - ii. Depress screw
 - iii. Release screw
 - iv. Depress screw
 - v. Release screw
 - vi. Restore screw in endplate

Note: The screw must be threaded into the endplate for normal operation. Failing to do so will cause the device to go into failsafe.

The LRV and URV have now been adjusted to zero the device without affecting the span.

After Rezeroing, it is possible to set the span by adjusting the URV with the span actuator. The span actuator should never be used to adjust the URV without using the zero actuator to set the LRV first.

URV or Full Scale Turndown is performed by applying any pressure, within the 6:1 ratio of the transmitter that you want to be the 20 mA point. When the pressure is held steady:

- a. SPX 2XXX/4XXX/5XXX (Pushbutton)
 - i. Do not remove seal screw when the circuit is live in a hazardous area.
 - ii. Remove span pushbutton seal screw.
 - iii. Using a 2mm or smaller Allen key, depress the pushbutton for a ¹/₂ second.
 - iv. Release pushbutton for a 1/2 second.
 - v. Depress the pushbutton again for a ½ second and release.
 - b. SPX 3XXX (Hall Effect Switch)
 - i. Unthread Span screw from endplate
 - ii. Depress screw
 - iii. Release screw
 - iv. Depress screw
 - v. Release screw
 - vi. Restore screw in endplate

Note: The screw must be threaded into the endplate for normal operation. Failing to do so will cause the device to go into failsafe.

The SPX has now adjusted the URV 20 mA point to match the pressure applied.

6.8 RERANGING VIA HART

Rerange LRV (4)

This is the pressure at which the transmitter will output 4 mA as entered directly by the user. Changing the LRV affects the transmitter span so the is range is limited by the minimum span value found in Fast Key (1,4,1,5)



Rerange URV (5)

This is the pressure at which the transmitter will output 20 mA as entered directly by the user. This range is limited by the minimum span value found in Fast Key (1,4,1,5)

Rerange TV LRV (1,3,3,3) SPX 3XXX "TB" option only

This is the temperature at which the transmitter will output 4 mA on the secondary mA output as entered directly by the user.

Rerange TV URV (1,3,3,4) SPX 3XXX "TB" option only

This is the temperature at which the transmitter will output 20 mA on the secondary mA output as entered directly by the user.

Rerange LRV By Applying Pressure (1,2,5,1,1,1,1)

This is done by applying a known pressure and initiating the procedure so that the transmitter adopts the pressure as the 4 mA point.

Note: This should only be performed with a Calibrated Pressure Source.

Rerange URV By Applying Pressure (1,2,5,1,1,1,2)

This is done by applying a known pressure and initiating the procedure so that the transmitter adopts the pressure as the 20 mA point.

Note: This should only be performed with a Calibrated Pressure Source.

Recall Factory Trim (1,2,5,3)

This is used to restore the Zero, Lower, and Upper Trim to the Values as set from the Factory.

R-Cal Set % (1,2,5,1,4,1)

This is used on versions with a Rcal. By activating R-Cal, the output will be set to the percentage of span set by this function. Default is 80%. Setting Rcal to 0%, disables the Rcal function.

Damping (1,3,5)

The damping time constant affects the speed with which the primary output signal reacts to changes in pressure as shown in the figure on the following page. Damping is off by default but values between 0 and 30 seconds can be set using the handheld communicator. The damping value must be entered in integers. If non-integers are entered, the system rounds to the next integer.





Profitability

Material Analysis

Sustainability

Local Actuator Disable (1,4,3,6)

Local zero and span actuators can be disabled using the HART handheld communicator function "Local Push-buttons." When turned off, the software Lock Out prevents changes to transmitter range points via the local zero and span actuators. With local Push-buttons disabled, changes to configuration are still possible via HART.

Status (1,2,1,2)

Reads Device Status from SPX.

PV Unit (1,3,2)

The pressure unit defines the unit of measure that the pressure-specific parameters are transmitted in. The SPX can be configured in the engineering units of psi, Bar, MPa, and kgf/cm² or as a percentage of Full Scale (FS). After selecting a new pressure unit, all entries for pressure are recalculated to the new unit, using the following conversion rules:

1 psi = 0.068947 Bar = 0.0068947 MPa = 0.070309 kgf/cm²

Tag (1,3,1)

An inventory "Tag" identification number may be stored in transmitter memory (8 characters maximum). Software tag is a single question mark by default.

Descriptor (1,3,4,2)

A 16 character text can be entered for further description of transmitter e.g. location, function, position, etc.

Message (1,3,4,3)

A 20 character message can be set and displayed on the HART Communicator.

SV Electronics Temperature (1,1,7)

Temperature measured on the Electronics Assembly is used for reference and factory diagnostics only.

TV Snout Temperature (1,1,4)



Temperature measured at the snout tip (SPX 3XXX only).

Poll Address (1,4,3,3,3)

Use in Multidrop mode allows more than one transmitter (up to 15) on a single loop. If this value is other than zero, the transmitter is in Multidrop mode. An example of Multidrop mode would be a group of HART devices wired in parallel on a single powered loop and each device being assigned a unique Poll address (1-15). The HART communicator would prompt for the individual address of the transmitter to communicate with and would only poll that specific device. All others would remain unchanged. Note: Analog output is set to 4mA when in multi-drop mode.

Burst Mode (1,4,2,3,1)

When the SPX 3XXX is used in Burst Mode, the transmitter outputs one-way digital communications from the transmitter to the Host. Communication rate is faster since the transmitter does not have to be polled to send data. Information transmitted in Burst Mode includes Pressure Variable, Analog Output value, Pressure in % of range. Access to other information can still be obtained through normal HART Comms.

6.9 RESETTING TO FACTORY DEFAULT SETTINGS

The factory settings for the sensor (including zero and span) can be restored if they are changed inadvertently using the Zero/Span Actuators or the HART communicator. The list of parameters restored is shown below.

Make sure Control System is in Manual mode. Temporary loss of Loop Output during Electronics Re-boot may occur.

To reset the sensor using the actuators, use the following procedure:

ATTENTION

a. SPX 2XXX/4XXX/5XXX (Pushbutton)

- i. Do not remove seal screw when the circuit is live in a hazardous area.
- ii. Remove zero and span pushbutton seal screws.
- iii. Using a 2mm or smaller Allen key, depress the pushbuttons for a ¹/₂ second.
- iv. Release pushbuttons for a ½ second.
- v. Depress the pushbuttons again for a ½ second and release.
- b. SPX 3XXX (Hall Effect Switch)
 - i. Unthread Zero and Span screws from endplate
 - ii. Depress screws
 - iii. Release screws
 - iv. Depress screws
 - v. Release screws
 - vi. Restore screws in endplate



Note: The screws must be threaded into the endplate for normal operation. Failing to do so will cause the device to go into failsafe.

At this point, the LRV and URV will be set to factory defaults.

6.10 DEFINITION OF "RESTORE FACTORY DEFAULTS"

- 1. Restore LRV and URV to their values at shipment.
- 2. Restore the Pressure Unit (psi, Bar, etc.) to its value at shipment.
- 3. Set the Analog Output Alarm Level to its value at shipment.
- 4. Remove all Pressure Damping
- 5. Clear all Sensor and Analog Output Trim values.
- 6. Clear Burst Mode.
- 7. Restore the Address to Zero.
- 8. Restore the Rcal option to its value at shipment. (Enable or Disable the Rcal option.)
- 9. Set actuators to the settings they were when shipped from DYNISCO.

6.11 HART COMMUNICATOR FAST KEY SEQUENCES

Below defines the HART Communicator Fast Key sequences. Fast Keys are a means of supplying a shortcut to navigate through the menu tree.



HART Communicator Fast Key sequences					
Function	Fast Key Sequence				
Read PV Pressure	2				
Read % of Full Scale	1,1,2				
Read Analog Output (PV)	1,1,3				
Read SV Electronics Temperature	1,1,7				
Read Peak Pressure Value	1,2,1,2				
Read Peak Electronic Temp Value (SV)	1,2,1,3				
Read Sensor Diagnostic Status	1,2,1,1				
Read PV Minimum Span	1,4,1,5				
Perform Sensor Self-Test	1,2,2				
Perform Sensor Master Reset	1,2,3				
Perform Loop Test	1,2,4				
Perform D/A Trim (PV)	1,2,5,1,2				
Perform Zero Trim	1,2,1,3,1				
Perform Lower Sensor Trim	1,2,5,1,3,2				
Perform Upper Sensor Trim	1,2,5,1,3,3				
Recall Factory Trim	1,2,5,3				
Set Rcal %	1,2,5,1,4,1				
Set Tag	1,3,1				
Set PV Unit	1,3,2				
Set Lower Range Value (LRV) (PV)	1,3,3,1				
Set Upper Range Value (URV) (PV)	1,3,3,2				
Display Lower Set Limit (LSL) (PV)	1,3,3,5				
Display Upper Set Limit (USL) (PV)	1,3,3,6				
Set Date	1,3,4,1				
Set Descriptor	1,3,4,2				
Set Message	1,3,4,3				
Set PV Damping	1,3,5				
Set SV Temperature Unit	1,4,1,7				
Set PV Analog Output Alarm Type	1,4,2,2,3				
Set Poll Address	1,4,2,3,1				
Set # of Request Preambles	1,4,2,3,2				
Set Burst Mode	1,4,2,3,3				
Set Burst Option	1,4,2,3,4				
Read Analog Output (TV)	1,1,6				
Read Peak Temp Value (TV)	1,2,3,4				
Perform D/A Trim (TV)	1,2,5,2,2				
Set Lower Range Value (LRV) (TV)	1,3,3,3				
Set Upper Range Value (URV) (TV)	1,3,3,4				
Temperature Override	1,2,5,2,1,1				
Temperature Override Value	1,2,5,2,1,2				

Vertication

Lo Metal

Profitability

Material Analysis

Sustainability



7 MAINTENANCE

7.1 MAINTENANCE

Mounting and electrical connection of the SPX must be done by specialists with EMC training, following all applicable regulations, and in **pressureless**, **voltage-free**, **intrinsically safe condition with the machine switched off.**



The machine must be secured against being switched back on!

ATTENTION

The most common causes of transducer damage are: installation in improperly machined or plugged mounting holes and cold starts. The tip of the transducer consists of a stainless steel diaphragm that must be protected from severe abrasives, dents and scores.



Burn Hazard! The SPX must be removed with the melt in the molten condition. The SPX can be very hot when removed. WEAR PROTECTIVE GLOVES!



Wear protective gloves!

Installation and Removal Instructions

- DO NOT REMOVE PROTECTIVE CAP UNTIL READY TO INSTALL.
- PRIOR TO INITIAL INSTALLATION, VERIFY CORRECT MACHINING OF MOUNTING HOLE.
- WHEN REINSTALLING, MAKE SURE MOUNTING HOLE IS CLEAR OF DEBRIS OR HARDENED PLASTIC.
- THE MEDIUM MUST BE IN MOLTEN CONDITION DURING TRANSDUCER REMOVAL.
- (Removing the transducer with the medium in a solidified condition can damage the sensor diaphragm.)
- ALWAYS REMOVE THE SPX BEFORE CLEANING THE MACHINE WITH ABRASIVES OR STEEL WIRE BRUSHES, ETC.
- DO NOT CLEAN THE "SCREWED-IN" SECTION OF THE SPX WITH HARD OBJECTS THIS WILL DAMAGE THE SPX.
- ALWAYS USE A TORQUE WRENCH APPLIED TO THE DESIGNATED HEXAGONAL COLLAR WHEN SCREWING THE PT IN AND OUT. DO NOT APPLY THE TOOL TO THE HOUSING OR HOUSING/ SENSOR CONNECTION.
- ELECTROSTATIC DISCHARGE MAY DAMAGE THE SPX TAKE ESD PRECAUTIONS.



7.2 REPAIR/DISPOSAL

Toxic hazard!

The SPX contains a small amount of mercury (Hg) as its standard transmission medium. If the diaphragm is damaged, mercury may escape. For alternate (non-Hg) transmission mediums please consult factory.

Never transport or store the SPX without the protective cap in place. Remove the cap shortly before installation.

If mercury is inhaled or swallowed, seek medical attention immediately!

Mercury is hazardous waste and must be disposed of in accordance with applicable laws. **DYNISCO** will accept defective SPXs.

If mercury escapes, use airtight packaging!

Please send defective SPX units back to your DYNISCO representative. For **DYNISCO** addresses, see the back cover of the operating manual.

7.3 WARRANTY

The SPX Series Dynisco Pressure transmitters will provide excellent service and superior performance if proper care is taken during handling, installation, and use. This DYNISCO product is warranted under terms and conditions set forth in the **DYNISCO** web pages. Go to <u>www.dynisco.com</u> and click on the "warranty" link under the "Post-Sales Support" tab at the top of the web page for complete details.



8 TROUBLESHOOTING

Symptom	Corrective Actions
Milliamp Reading is Zero	1) Check if Power Polarity is Reversed
	2) Verify Voltage Across Transmitter Pins
Large Zero Shift when Screwing In	1) Check Hole with Gage Plug and Rework Hole as Required
	2) Check Mounting Torque
Primary Milliamp Reading is Low or	1) Check Pressure Variable Reading for Saturation
High	2) Check if Output in Alarm Condition
	3) Verify 4 and 20 mA Range Points or Simply Reset
	4) Perform 4 - 20 mA Output Trim with HART Communicator
No Response to Changes in Applied	1) Check Test Equipment
Pressure	2) Check Port/Pipe for Blockage or Solidified Plastic
	3) Check if Output in Alarm Condition
	4) Check if in multi-drop mode
Pressure Variable Reading is Low or	1) Check Test Equipment
High	2) Check Port/Pipe for Blockage or Solidified Plastic
	3) Perform Full Sensor Trim
Pressure Variable Reading is Erratic	1) Check Port/Pipe for Blockage or Solidified Plastic
	2) Check Damping
	3) Check for EMI
Transmitter Not Communicating with	1) Check Power Supply Voltage at Transmitter
HART Communicator	2) Check Load Resistance (250 Ohm minimum)
	3) Check Communicator Connection Across Power Supply
	Check if Unit is Addressed Properly
	5) Confirm HART communicator is connected to primary
	(Pressure) output 4-20mA
HART Communicator missing SPX	From the Communicator's Main Menu, Access the On-Line
Features Described in Manual	Menu. The Name SPX Should be Displayed on the Top Line of
	the LCD. If the Name is not Present, Contact Dynisco to
	Arrange for DD Upgrade
Secondary output at or below 3.6mA	1) Confirm output option is specified in Model configuration
(Failsafe low)	2) Confirm that primary output is properly powered
Primary output =3.6mA or > 21mA	1) Unit is in fail safe, consult fail safe section

let fication

La Merill

Profitability

Material Analysis

Sustainability



9 ACCESSORIES

- Machining tool kit 1/2"-20UNF-2A P/N 200295
- Cleaning tool kit 1/2"-20UNF-2A P/N 200100
- Machining tool kit M18 x1.5 P/N 200105
- Cleaning tool kit M18 x1.5 P/N 200101
- Mounting Bracket P/N 190925



10 APPROVALS/CERTIFICATES

10.1	CE DECLARATION OF CONFORMITY	57
10.2	EC-TYPE EXAMINATION CERTIFICATE	59
10.3	EX FM CERTIFICATE OF COMPLIANCE – SPX 2XXX/5XXX	63
10.4	EX FM CERTIFICATE OF COMPLIANCE – SPX 3XXX	68
10.5	EX FM CERTIFICATE OF COMPLIANCE – SPX 3XXX	71

Note additional approvals available; please consult factory.



10.1 CE DECLARATION OF CONFORMITY

<image/> <image/> <section-header><section-header><section-header><section-header><section-header><section-header><section-header><section-header><section-header><section-header><section-header></section-header></section-header></section-header></section-header></section-header></section-header></section-header></section-header></section-header></section-header></section-header>		
<section-header><section-header><text><text><text><text><text><text><text><text><text><text><text><text><text><text><text><text><text><text><text><text></text></text></text></text></text></text></text></text></text></text></text></text></text></text></text></text></text></text></text></text></section-header></section-header>		Dynisco CE
We, the manufacturer, Dynisco Instruments, 38 Forge Parkway, Franklin, MA 02038 USA declare under our sole responsibility that the products: Product Series: SPX (ERX) SPX: 14 , SPX-L Pressure Transmitters Partial Type Designations 2*** (SPX: 6EN2) 3**** (SPX: 1) where an asterisk "** represents any letter, number, or character where partial type designations above represents the first 4 characters of the full type designation to which this declaration relates, are in conformity with the standards or other normative documents following the provisions of the respective European Union Directives listed below: PMC Directive 2014/30/EU – Electromagnetic Compatibility All Type Designations EN 61326-1:2013 (EEC 61326-1:2012) CISPR 11:2009-41:2010 Radiated Electromagnetic Emissions EEC 61000-42:2008 Electrostatic Discharge Immunity EEC 61000-42:2008 Electrostatic Discharge Immunity EEC 61000-42:2010 Radiated Electromagnetic Field Immunity EEC 61000-42:2008 Electrostatic Discharge Immunity EEC 61000-42:2020 Belectrostatic Discharge Immunity EEC 61000-45:2008 Radio Frequency Common Mode Immunity EEC 61000-45:2008 Radio Frequency Common Mode Immunity EEC 61000-45:2008 Radio Frequency Common Mode Immunity EC 61000-65:2008 Fallow	_	EU Declaration of Conformity
Product Series: SPX GEN2, SPX-T, & SPX-L Pressure Transmitters Partial Type Designations: 2*** (SPX GEN2) 3**** (SPX T) 4**** (SPX GEN2) 5*** (SPX T) where an asterisk "** represents any letter, number, or character where partial type designations above represents the first 4 characters of the full type designation to which this declaration relates, are in conformity with the standards or other normative documents following the provisions of the respective European Union Directives listed below: EMC Directive 2014/30/EU - Electromagnetic Compatibility All Type Designations EN 61326-1:2013 (IEC 61326-1:2012) CISPR 11:2009-41:2010 Radiated Electromagnetic Failssions IEC 61000-4-3:2010 Radiated Electromagnetic Failssions IEC 61000-4-3:2010 Radiated Electromagnetic Fails for the standards or other normative documents following the provision of the respective European Union Directives 15ted below: PMC Directive 2014/30/EU - Electromagnetic Fails Immunity IEC 61000-4-3:2010 Radiated Electromagnetic Fails Fails Type Designations 228* and 538* with: Pressure Range Code less than or equal to "20" (200 Bar/3000 psi) Sound Engineering Practice (SEP) apples. Partial Type Designations ID and Edit fails for scope of the PED directive and therefore the PED directive shall not apply. Conformity Assessment Module "A" applies. All other Type Designations 228* and 538* with: Pressure Range Code less than or equal to "20" (200 Bar/3000 psi) Conformity Assessment Module "A" applies. All other Type Designations 27**, 3***, 4*** & 5**** with: Hazordos Fail Catasification Code "5" (Intrinsically Safe ATEX, EU) The declared products described above are in conformity with the relevant Union harmonization legislation. Fulfilment of the essentification Code "5" (Intrinsically Safe ATEX, EU) The declar		We, the manufacturer, Dynisco Instruments, 38 Forge Parkway, Franklin, MA 02038 USA declare under our sole responsibility that the products:
to which this declaration relates, are in conformity with the standards or other normative documents following the provisions of the respective European Union Directives listed below: EMC Directive 2014/30/EU – Electromagnetic Compatibility All Type Designations EN 61326-1:2013 (EC 61326-1:2012) CISPR 11:2009+A1:2010 Radiated Electromagnetic Emissions IEC 61000-4:2:2008 Radiated Electromagnetic feeld Immunity IEC 61000-4:2:2018 Radiated Electromagnetic feeld Immunity IEC 61000-4:2:2008 Radia Fraquency Common Mode Immunity IEC 61000-4:6:2008 Radio Frequency Common Mode Immunity PED Directive 2014/68/EU – Pressure Equipment Partial Type Designations 228* and 538* with: Pressure Range Code Jess than or equal to "20" (200 Bar/3000 psi) Sound Engineering Practice (SEP) applies. Partial Type Designations 228* and 538* with: Pressure Range Code greater than "20" (200 Bar/3000 psi) Conformity Assessment Module "A" applies. All ther Type Designations 228* and 538* with: Pressure Range Code greater than "20" (200 Bar/3000 psi) Conformity Assessment Module "A" applies. All ther Type Designations 228* and 538* with: Pressure Range Code greater than "20" (200 Bar/3000 psi) Conformity Assessment Module "A" applies. All ther Type Designations 2***, 3***, 4*** & 5**** with: Hazardous Area Classification Code "5" (Intrinsfcally Safe ATEX, EU) The declared products described above sers in conformity with the relevant Union harmonization legislation. Fulfillment of the essential health and safety requirements set out in Annex II has been demonstrated by compliance with: Current Harmonized Sandards BE N IEC 60079-0:2018 General requirements BE N IEC 60079-0:20		Product Series: SPX GEN2, SPX-T & SPX-L Pressure Transmitters Partial Type Designations: 2*** (SPX2 GEN2) 3*** (SPX-T) 4*** (SPX4 GEN2) 5*** (SPX-L) where an asterisk "*" represents any letter, number, or character where partial type designations above represents the first 4 characters of the full type designation
EMC Directive 2014/30/EU – Electromagnetic Compatibility All Type Designations EN 61326-1:2013 (EC 61326-1:2012) CISPR 11:2009-41:2010 Radiated Electromagnetic Emissions IEC 61000-4-2:2008 Electrostatic Discharge Immunity IEC 61000-4-3:2012 Electric Fast Transient Burst Immunity IEC 61000-4-3:2012 Electric Transient Burst Immunity IEC 61000-4-6:2008 Radio Frequency Common Mode Immunity IEC 61000-4-6:2008 Radio Frequency Camo Mode Immunity IEC 61000-10-2014/34/EU – Pressure equipment must have "a pressure bearing housing", which is compellingly related to an identifiable pressure chamber. ATEX Directive 2014/34/EU – Potentially Explosive Atmospheres Partial Type Designations 2***, 3***, 4*** & 5*** with: Hardous Area Classification Code "S" (Intrinsically FATE) FLT Hardous Area Classification Code "S" (Intrinsical FATE), FLT Hardous Area Classifi		to which this declaration relates, are in conformity with the standards or other normative documents following the provisions of the respective European Union Directives listed below:
All Type Designations EN 61326-1:2013 (EC 61326-1:2012) CTSPR 11:2009-A1:2010 Radiated Electromagnetic Emissions IEC 61000-4-2:2008 Electrostatic Discharge Immunity IEC 61000-4-2:2008 Electrostatic Discharge Immunity IEC 61000-4-2:2012 Electric Fast Transient Burst Immunity IEC 61000-4-2:2008 Radio Frequency Common Mode Immunity IEC 61000-4-6:2008 Radio Frequency Common Mode Immunity Partial Type Designations 228* and 538* with: Pressure Range Code greater than "20" (200 Bar/3000 psi) Conformity Assessment Module "A" applies. All other Type Designations These models fall outside the scope of the PED directive and therefore the PED directive shall not apply. Partial Type Designations 2***, 3*** & \$*** & \$*** With: Hazardous Area Classification Code "S" (Intrinsically Safe ATEX, EU) The declared products described above are in conformity with the relevant Union harmonization legislation. Fulfilliment of the essential health and safety requirements set out in Annex II has been demonstrated by compliance with: Current Harmonized Standards BS EN IEC 60079-0:2018 General requirements EN 60079-0:2019 Equipment with equipment protection level (EPL) Ga EN 1127-1:2011 Explosion prevention and protection. Basic concept		EMC Directive 2014/30/EU – Electromagnetic Compatibility
PED Directive 2014/68/EU - Pressure Equipment Partial Type Designations 228* and 538* with: Pressure Range Code less than or equal to "20" (200 Bar/3000 psi) Sound Engineering Practice (SEP) applies. Partial Type Designations 228* and 538* with: Pressure Range Code greater than "20" (200 Bar/3000 psi) Conformity Assessment Module "A" applies. All other Type Designations These models fall outside the scope of the PED directive and therefore the PED directive shall not apply. Per the PED directive article 2, number (5); pressure equipment must have "a pressure bearing housing", which is compellingly related to an identifiable pressure chamber. ATEX Directive 2014/34/EU - Potentially Explosive Atmospheres Partial Type Designations 2***, 3***, 4*** & 5*** with: Hazardous Area Classification Code "S" (Intrinsically Safe ATEX, EU) The declared products described above are in conformity with the relevant Union harmonization legislation. Fulfilment of the essential health and safety requirements set out in Annex II has been demonstrated by compliance with: Current Harmonized Standards BS EN IEC 60079-0:2018 General requirements EN 60079-11:2012 Intrinsic safety "1" EN 60079-2:2015 Equipment with equipment protection level (EPL) Ga EN 1127-1:2011 Explosion prevention and protection. Basic concepts and methodology <		All Type Designations EN 61326-1:2013 (IEC 61326-1:2012) CISPR 11:2009+A1:2010 Radiated Electromagnetic Emissions IEC 61000-4-2:2008 Electrostatic Discharge Immunity IEC 61000-4-3:2010 Radiated Electromagnetic Field Immunity IEC 61000-4-4:2012 Electric Fast Transient Burst Immunity IEC 61000-4-5:2005 Surge Immunity IEC 61000-4-6:2008 Radio Frequency Common Mode Immunity
Partial Type Designations 228* and 538* with: Pressure Range Code less than or equal to "20" (200 Bar/3000 psi) Sound Engineering Practice (SEP) applies. Partial Type Designations 228* and 538* with: Pressure Range Code greater than "20" (200 Bar/3000 psi) Conformity Assessment Module "A" applies. All other Type Designations These models fall outside the scope of the PED directive and therefore the PED directive shall not apply. Per the PED directive article 2, number (5); pressure equipment must have "a pressure bearing housing", which is compellingly related to an identifiable pressure chamber. ATEX Directive 2014/34/EU – Potentially Explosive Atmospheres Partial Type Designations 2***, 3***, 4*** & 5*** with: Hazardous Area Classification Code "S" (Intrinsically Safe ATEX, EU) The declared products described above are in conformity with the relevant Union harmonization legislation. Fulfillment of the essential health and safety requirements set out in Annex II has been demonstrated by compliance with: Current Harmonized Standards BS EN IEC 60079-0:2018 General requirements EN 60079-11:2012 Intrinsic safety "" EN 60079-26:2015 Equipment with equipment protection level (EPL) Ga EN 1127-1:2011 Explosion prevention and protection. Basic concepts and methodology P/N 973002 ECO# 50070 Rev. K		PED Directive 2014/68/EU – Pressure Equipment
Partial Type Designations 228* and 538* with: Pressure Range Code greater than "20" (200 Bar/3000 psi) Conformity Assessment Module "A" applies. All other Type Designations These models fall outside the scope of the PED directive and therefore the PED directive shall not apply. Per the PED directive article 2, number (5); pressure equipment must have "a pressure bearing housing", which is compellingly related to an identifiable pressure chamber. ATEX Directive 2014/34/EU – Potentially Explosive Atmospheres Partial Type Designations 2***, 3***, 4*** & 5*** with: Hazardous Area Classification Code "S" (Intrinsically Safe ATEX, EU) The declared products described above are in conformity with the relevant Union harmonization legislation. Fulfillment of the essential health and safety requirements set out in Annex II has been demonstrated by compliance with: Current Harmonized Standards BS EN IEC 60079-0:2018 General requirements EN 60079-12:201 Intrinsic safety "I" EN 60079-26:2015 Equipment with equipment protection level (EPL) Ga EN 1127-1:2011 Explosion prevention and protection. Basic concepts and methodology 'age 1 of 3 P/N 973002 ECC# 50070 Rev. K		Partial Type Designations 228* and 538* with: Pressure Range Code less than or equal to "20" (200 Bar/3000 psi) Sound Engineering Practice (SEP) applies.
All other Type Designations These models fall outside the scope of the PED directive and therefore the PED directive shall not apply. Per the PED directive article 2, number (5); pressure equipment must have "a pressure bearing housing", which is compellingly related to an identifiable pressure chamber. ATEX Directive 2014/34/EU – Potentially Explosive Atmospheres Partial Type Designations 2***, 3***, 4*** & 5*** with: Hazardous Area Classification Code "S" (Intrinsically Safe ATEX, EU) The declared products described above are in conformity with the relevant Union harmonization legislation. Fulfillment of the essential health and safety requirements set out in Annex II has been demonstrated by compliance with: Current Harmonized Standards BS EN IEC 60079-0:2018 General requirements EN 60079-0:2015 Equipment with equipment protection level (EPL) Ga EN 1127-1:2011 Explosion prevention and protection. Basic concepts and methodology P/N 973002 ECC# 50070 Rev. K		Partial Type Designations 228* and 538* with: Pressure Range Code greater than "20" (200 Bar/3000 psi) Conformity Assessment Module "A" applies.
Per the PED directive article 2, number (5); pressure equipment must have "a pressure bearing housing", which is compellingly related to an identifiable pressure chamber. ATEX Directive 2014/34/EU – Potentially Explosive Atmospheres Partial Type Designations 2***, 3***, 4*** & 5*** with: Hazardous Area Classification Code "S" (Intrinsically Safe ATEX, EU) The declared products described above are in conformity with the relevant Union harmonization legislation. Fulfillment of the essential health and safety requirements set out in Annex II has been demonstrated by compliance with: Current Harmonized Standards BS EN IEC 60079-0:2018 General requirements EN 60079-11:2012 Intrinsic safety "i" EN 60079-26:2015 Equipment with equipment protection level (EPL) Ga EN 1127-1:2011 Explosion prevention and protection. Basic concepts and methodology P/N 973002 ECO# 50070 Rev. K		All other Type Designations These models fall outside the scope of the PED directive and therefore the PED directive shall not apply.
ATEX Directive 2014/34/EU – Potentially Explosive Atmospheres Partial Type Designations 2***, 3***, 4*** & 5*** with: Hazardous Area Classification Code "S" (Intrinsically Safe ATEX, EU) The declared products described above are in conformity with the relevant Union harmonization legislation. Fulfilment of the essential health and safety requirements set out in Annex II has been demonstrated by compliance with: Current Harmonized Standards BS EN IEC 60079-0:2018 General requirements EN 60079-11:2012 Intrinsic safety "i" EN 60079-26:2015 Equipment with equipment protection level (EPL) Ga EN 1127-1:2011 Explosion prevention and protection. Basic concepts and methodology P/N 973002 ECO# 50070 Rev. K		Per the PED directive article 2, number (5); pressure equipment must have "a pressure bearing housing", which is compellingly related to an identifiable pressure chamber.
Current Harmonized Standards BS EN IEC 60079-0:2018 General requirements EN 60079-11:2012 Intrinsic safety "i" EN 60079-26:2015 Equipment with equipment protection level (EPL) Ga EN 1127-1:2011 Explosion prevention and protection. Basic concepts and methodology 'age 1 of 3 P/N 973002 ECO# 50070 Rev. K		ATEX Directive 2014/34/EU – Potentially Explosive Atmospheres Partial Type Designations 2***, 3***, 4*** & 5*** with: Hazardous Area Classification Code "S" (Intrinsically Safe ATEX, EU) The declared products described above are in conformity with the relevant Union harmonization legislation. Fulfillment of the essential health and safety requirements set out in Annex II has been demonstrated by compliance with:
Page 1 of 3 P/N 973002 ECO# 50070 Rev. K		Current Harmonized Standards BS EN IEC 60079-0:2018 General requirements EN 60079-11:2012 Intrinsic safety "i" EN 60079-26:2015 Equipment with equipment protection level (EPL) Ga EN 1127-1:2011 Explosion prevention and protection. Basic concepts and methodology
	Page 1	L of 3 P/N 973002 ECO# 50070 Rev. K

rifeation

La Metil

Profitability

Material Analysis

Sustainability





Profitability

Material Analysis

Sustainability

Dynisco CE
Sira Certification Service (SIRA) Unit 6 Hawarden Industrial Park
Hawarden, Deeside CH5 3US, United Kingdom
ATEX Directive 2014/34/EU – Potentially Explosive Atmospheres
Partial Type Designations 2*** and 5*** with: Hazardous Area Classification Code "T" (Dust ignition protection by enclosure ATEX, EU)
The declared products described above are in conformity with the relevant Union harmonization legislation. Fulfillment of the essential health and safety requirements set out in Annex II has been demonstrated by compliance with:
Current Harmonized Standards
EN 60079-31:2014 Equipment dust ignition protection by enclosure "t"
The current harmonized standards have been compared to the superseded standards listed in the SPX Dust ATEX to technical file (P/N 974140) and no changes in the "state of the art" apply to the equipment. Annual Gap Analysis Report P/N 973003. See below for specific standard gap analysis reports.
Superseded Standards listed in the SPX Dust ATEX to technical file EN 60079-0:2012+A11:2013 General requirements (gap analysis P/N 975356)
Equipment Group II, Category 3 D Ex tc IIIC T100°C Dc
Authorized Representative established within the Community: Dynisco Europe GmbH Pfaffenstr. 21 74078 Heilbronn, Germany
Other information:
 Device testing per normative standards following the EMC Directive (2014/30/EU) was conducted by: Chomerics Test Services, Woburn, Massachusetts, USA / 24-26 June 2013 / American Association for Laboratory Accreditation (A2LA) accredited facility, Certificate Number 1980.01.
 Dust ignition protection by enclosure device testing and documentation per normative standards following Annex VIII of the ATEX Directive (2014/34/EU) were conducted and prepared by the manufacturer, Dynisco Instruments / January 2018.
Date of issue: 28 March 2019
John Clazasty Vice President of Engineering
Page 3 of 3 P/N 973002 500# 50070 Perc K
174 57562 LCO# 50070 KeV. K



10.2 EC-TYPE EXAMINATION CERTIFICATE

		R	F ∂	
(1)	EC-TYPE	E-EXAMINATIO		CATE
(2)	Equipment and Protectiv	ve Systems Intended for Use in	1	
(3)	Foremany Explosive An	nospheres - Directive 94/9	UEC.	(Ex)
(~)	co que examinador de	PTB 09 ATEX	2038 X	
(4)	Environent	Pressure transmi	tter type series SPX-T	and SPXGEN2
(5)	Manufacturer:	Dynisco Instrume	ents	and of House
(6)	Address:	38 Forge Parkwa	y, Franklin, MA 02038,	USA
(7)	This equipment and any the documents therein re-	acceptable variation thereto elerred to.	are specified in the sche	dule to this certificale and
(8)	The Physikalisch-Techn Council Directive 94/9/E the Essential Health an protective systems inte Directive.	ische Bundesanstalt, notified C of 23 March 1994, certifies d Safety Requirements relatin nded for use in potentially	body No. 0102 in accord that this equipment has I g to the design and cons explosive atmospheres,	tance with Article 9 of the been found to comply with inuction of equipment and given in Annex II to the
	The examination and ter 29142 .	st results are recorded in the o	confidential assessment a	nd test report PTB Ex 08-
(9)	Compliance with the Ess	ential Health and Safety Requ	uirements has been assur	ed by compliance with:
	EN 60079-0:2006	EN 60079-11:2007	EN 60079-26:2007	EN 1127-1:2007
(10)	If the sign "X" is placed conditions for safe use s	after the certificate number, pecified in the schedule to this	it indicates that the equip s certificate.	ment is subject to special
(11)	This EC-type-examination Certificate relates only to the design, examination and tests of the specified equipment in accordance to the Directive \$4/9/EC. Further requirements of the Directive apply to the manufacturing process and supply of this equipment. These are not covered by this certificate.			
(12)	The marking of the equip	pment shall include the following	ng:	
	🕼 II 1 G	Ex ia IIC T6 / T4 or	🕢 11 2 G Ex ia	IIC T4 / T6
	Zertifizierungssektor E By order: DrIngi U. Gerlade Oberregierungsraf	Add at the	Braunsch	weig, October 20, 2009

feato

La Metil

Profitability

Material Analysis

Sustainability





For relationship between maximum permissible ambient temperature, maximum permissible medium temperature and temperature class reference is made to the following table:

temperature class	T6	T4
max. permissible ambient temperature	60 °C	85 °C
max. permissible medium temperature	60 °C	85 °C

The minimum permissible ambient and medium temperature is: -20 °C.

sheet 2/4

EC-type-examination Certificates without signature and official stamp shall not be valid. The certificates may be circulated only without alteration. Extracts or alterations are subject to approval by the Physikalisch-Technische Bundesanstalt. In case of dispute, the German text shall prevail. Physikalisch-Technische Bundesanstalt • Bundesallee 100 • 38116 Braunschweig • GERMANY

P/N 975161 ECO 35645 Rev. A

Dynisco

Profitability

Material Analysis

Sustainability





Profitability

Material Analysis

Sustainability



Ph	vsikalisch-Technische Bundesanstalt PIB
Real	
Brai	
SUP	DULE TO EC-ITPE-EXAMINATION CERTIFICATE PTB 09 ATEX 2036 X
(17)	Special conditions for safe use
	 The housing of the pressure transmitters, type series SPX-T and SPXGEN2 shall be connected reliably to the local equipotential bonding system.
	Those variants of the pressure transmitters, type series SPX-T and SPXGEN2 which include the material aluminium, shall be installed in such a way that sparking as a result of impact or friction between aluminium and steel is excluded. Impact or friction between aluminium and stainless steel is allowed if the existence of rust particles can be excluded.
	 For application as category-1-equipment the connecting cable shall be equipped with a suitable conductive coating (R_{eurlace} < 10⁹ Ω) to avoid possible electrostatic charge.
(18)	Essential health and safety requirements
	met by compliance with the standards mentioned above
	DrIng. U. Gerlach Oberregierungsräften 21 1111
	sheat AlA

Profitability

Material Analysis

Sustainability

Verfication

Lo Metal



.0.3	EXFM CERTIFICATE OF COMPLIANO	CE – SPX2XXX/5XXX	
		PM Approvals 1151 Boston Providence Tumpike P.O. Box 9102 Norwood, MA 02062 USA 1: 781 762 4300 F: 781-762-9375 www.finapprovals.com	vals:
	CERTIFICATE	OF COMPLIANCE	
	HAZARDOUS (CLASSIFIED) [LOCATION ELECTRICAL EQUIPMENT	
	This certificate is issued for the following	equipment:	
	228aEbcCdefghl. SPX Smart Pressure Transm XP/I/1/ABCD/T5 Ta=85C, T6 Ta=60C DIP/II.III/1/EFG/T5 Ta=85C, T6 Ta=60C; Type 4) a = Accuracy 0, 1, or 2. b = Pressure reference E, N, H, R, A, B, K, C, M, c = Process connection A, B, C, D, E, F, G, H, K, d = Cable length code (one digit alpha-numeric) e = Wiring Connections 4 or 9. f = Pressure units B, C, K, M, or P. g = Pressure range code 10 through 32. h = Hart communications A, B or C. i = Option code (four digits alpha-numeric) 'If Pressure Range code is less than 14 and Pret and IP67 ratings are not included.	alitter K*, IP67* .G. D. L. F. P. or S. L. M. N. P. R. or S. ssure Reference Code (b = B. K. C. M or G) then Type 4X.	
	229æEbcdefghC/22/, SPX Smart Pressure Tran XP//11/ABCD/T5 Ta=85C, T6 Ta=60C DIP/II,III/12FG/T5 Ta=85C, T6 Ta=60C, Type 40 a = Mounting configuration 0, 1, or 2. b = Process diaphragm material (one digit alpha- c = Process connection code (two digits alpha-nu d = Pressure units B, C, K, M, or P, e = Pressure range 08 through 23. f = Rigid snout length code (two digits alpha-num g = Flex length code (two digits alpha-numeric). h = Hart communications A, B or C. i = Cable length code (one digit alpha-numeric). j = Option codes (four digits alpha-numeric).	namilter K, IP67 numeric). meric).	
	PM Approvals HLC 6/07	3018521 age 1 of 5	Dynisco P/N 975174 ECO 36908 Rev. A

Vertication

Lo Metal

Profitability

Material Analysis

Sustainability





Material Analysis

Sustainability

Profitability

2241EabcdefgChZZI. SPX Smart Pressure Transmitter XP/I/1/ABCD/T5 Ta=85C, T6 Ta=60C

in Mell

- DIP/II,III/1/EFG/T5 Ta=85C; T6 Ta=60C; Type 4X, IP67
- a = Process diaphragm material (one digit alpha-numeric).
- b = Process connection code (two digits alpha-numeric).
- c = Pressure units B, C, K, M, or P.
- d = Pressure range 08 through 23
- e = Rigid snout length code (two digits alpha-numeric).
- f = Flex length code (two digits alpha-numeric).
- g = Hart communications A, B or C
- h = Cable length code (one digit alpha-numeric).
- i = Option codes (four digits alpha-numeric).

2242EabcdefgChZZI. SPX Smart Pressure Transmitter

XP/I/1/ABCD/T5 Ta=85C, T6 Ta=60C

DIP/II.III/1/EFG/T5 Ta=85C, T6 Ta=60C; Type 4X, IP67

- a = Process diaphragm material (one digit alpha-numeric).
- b = Process connection code (two digits alpha-numeric). c = Pressure units B, C, K, M, or P.
- d = Pressure range 08 through 27
- e = Rigid snout length code (two digits alpha-numeric).
- f = Flex length code (two digits alpha-numeric).
- g = Hart communications A, B or C
- h = Cable length code (one digit alpha-numeric).
- i = Option codes (four digits alpha-numeric)

2243EabcdefgChZZI. SPX Smart Pressure Transmitter XP/J/1/ABCD/T5 Ta=85C, T6 Ta=60C

DIP/II,III/1/EFG/T5 Ta=86C, T6 Ta=60C; Type 4X, IP67

- a * Process diaphragm material (one digit alpha-numeric).
- b = Process connection code (two digits alpha-numeric).
- c = Pressure units B, C, K, M, or P
- d = Pressure range 06 through 27
- e = Rigid snout length code (two digits alpha-numeric).
- f = Flex length code (two digits alpha-numeric).
- g = Hart communications A, B or C
- h = Cable length code (one digit alpha-numeric).
- i = Option codes (four digits alpha-numeric).

2244EabcdefgChZZi. SPX Smart Pressure Transmitter

XP/I/1/ABCD/T5 Ta=85C, T6 Ta=60C DIP/II,III/1/EFG/T5 Ta=85C, T6 Ta=60C; Type 4X, IP67

- a = Process diaphragm material (one digit alpha-numeric)
- b = Process connection code (two digits alpha-numeric).
- c = Pressure units B, C, K, M, or P
- d = Pressure range 08 through 23
- e = Rigid snout length code (two digits alpha-numeric).
- f = Flex length code (two digits alpha-numeric).
- g = Hart communications A, B or C.
- h = Cable length code (one digit alpha-numeric).
- i = Option codes (four digits alpha-numeric).

FM Approvals HLC 6/07	3018521	Dynisco P/N 975174
	Page 2 of 5	ECO 36906
		Rev A





Profitability

Material Analysis

(and

Sustainability

in Mell





Profitability

Material Analysis

Sustainability



			< FM Appro	ovals
This certifies that the Approval Standards a	equipment described nd other documents:	has been found to c	omply with the following	
Class 3600 Class 3615 Class 3810 IEC 60529 ANSUNEMA 250	1998 2005 2005 2004 1991			
Original Project ID: 3	018521	Approval Granted:	July 22, 2004	
Subsequent Revision Report Number 081218 3039284	Reports / Date Appro Date January 20, 2009 September 29, 2010	oval Amended Report Number	Date	
FM Approvals LLC	ſ			
J/E. Marquedaht Group Manager, Electrical	1 2		27 Septembe Date	1_7010
				Duri

Profitability

Material Analysis

Sustainability

Verfication

Lo Metal



10.4 EXFM CERTIFICATE OF COMPLIANCE – SPX 3XXX

	EM Approval EM Approval EP EL Construction of Compile Providence Overview, MAC (ONE) (C. C. E TRE TRE 4400 (C. 1910) (C. 2017) Source (Reapping do 200	orovals [.]
CERTIFI	CATE OF COMPLIANCE	
HAZARDÓUS (CL	ASSIFIED) LOCATION ELECTRICAL EQUIPMENT	
This certificate is issued to	n the following equipment	
Se42Ebrokefghyk, SPX-7 SA XP IS/1+1/ ABCD/TS Ta= DIP-IS/31+1/1/FFG/TS T Type 4X IPS/ a = Accuracy Codn 2 at 3 b = Process Durahung = Mate X or X = Process Durahung = Mate S or X = Process Durahung = Mate Distance Range Code 3 = Process Code (STOR B) = 1 MoSa Mate A at 2 at 2 at 3 at 3 at 3 at 3 at 3 at 3	nert Pressure Transmitter. B&*C TSTD=60*C - 3006*0 9-65*C T6T9-60*C - 3006*0 mailCode A & C D.E T G M J K L M N P R S F D V W 9 00 01, 02, 03, 04 05, 06, 07, 08 09 10, 11, 12 13 14, or 15 8 C K M. or P 8 te 77 representing 1 19*1a 36.5* teoring 3*a 35.3* du A 6, or C de CA C3 CC CD CE, CA, CG, CW CX, srCY du 72 or T8 5 B200 90% B5/6 B541 0493 M525 M640 M554, M/62 0 zat - any three digit code performing to output calibration	
Javi36bc datghlyk, SPX-T SA XP-(57, 717ASCD) T5 Ta- D P-IS 11111117(D) G 715 T Type 4X, P67 a - Accuracy Code 2 or 0 b - Process D aphrogm Mate X, or Y c - Process Connection God d = Programming Units Code e - Pressure Range Code G 11 Miga Shout Sength Code g = Flos Length Code repres	овг ГРазасиа Тлаозлийног. 85°С, ТБ Та-60°С - 000810 анво°С 19 Панбо°С - 330610 ма:Софа А, Е, С. Э, Е. Р. С, Н. Ј, К. І. М. М, Р, Р, S, Т. Џ, V, М е. 25 Ic 4C В, С. К. М. ан Р 81а 27 Чергезелиод 1, 19° to 35 5° метогод 01 Ic 35 3°	
- الما كور رحمه القرار ولي "	2001012 Page 1 of a	na da a Angla Agai





Profitability

Material Analysis

Sustainability



			< FM Àpp	tovals:
This certifies that the d	vauroment descal	oed has been (cund to	comply with the to lowing	
Approval Standards a	to other documer	nts		
Class 3000	'59 8			
Class 3615 Class 3610	2003			
Class 3310 Angharna 250	2005			
ANSI//EC-50529	2004			
Original Project ID: 30	35512	Approval Granted	d: June 24 2009	
Subsequent Rousion I	Reports / Dale Ag	pproval Amended		
Report Number	Date (< o e v2	Report Number	Date	
CH0707	2910, 40.7			
FM Approvats LLC				
FI:				
	(Note 5 2	a
Q. i nov	- M		Day of the second	7
Redeville Marties St	a p			
Roteri L Marte: Ji Drector	a f			
Robert L. Marter, Jr Director	a fr			
Reveall Marter Jr Brecker	a ge			

Profitability

Material Analysis

Sustainability

Verfication

Auriterin



10.5 Safety Integrity and Performance Level Applications





Page 2 of Ce	runcate No. 368/FSP 1205.0		TÜVRheinland Precisely Right.
Salety lunction.	Measuring of pressure and output of to the sensor. The total valid range o maximum of 20.5 mA (Factory Defay The safety reliated function of the tra- or the span (worst-case), Monitoring safety device, the transmitter is com or greater than 21 mA as failure con the high alarms or low alarms as a s traitine. The transmitters of the Guardian Ser-	an analogue signal 4 – 20mA prop r the output signal shall be configur it), namifier is the safe measurement o for an excessive pressure conditor deted to. This safety device has to ditions. It must be configured to reo aftery trip and secondary atams as tes contain a separate HW monitor	ordional to the volume pressure applied as to a minimum of 3.6 mA and a The pressure with a tolerance of +0.5% inas to be performed in the downstream read output ourients lower than 3.5 mA ognize the configured pressure range for defined by NAMUR are diagnostic ing channel for excessive pressure. In
	take the conducto over pressure v It has to be considered, that it is not a pressure and the monitoring output same machine. In this case 2 differences	and is exceeded the contact of the allowed to use the analogue output of the same transmitter for monitor it devices have to be used (see EN	ourput relay opens. of a combi-transmitter for the control of fing of an over-pressure condition at the (1114-1, gl. 5.2.5).
Characterist	ics as per IEC 61508	Value	
OIL		SIL 2 (HFT - 0 architect	re. 1001)
Device Type	e	D	
Mode of operato	n	Low demand mode	
OFF		DPX Series 2 DPX Series 3 SPX Series 3 DPX Series 5 SPX Series Industrial Guardian	78% 79% 78% 78%
Recommended 1	the interval for proof-testing T1	1 year	
PPD _{eng} torTi•	і унаг	SPX Series 2 DPX Series 3 SPX Series 4 SPX Series 5 SPX Series 5 SPX Series Industrial Guardian	4.5x10 ⁴ 2.1x10 ⁶ 4.5x10 ⁶ 4.5x10 ⁶ 4.5x10 ⁶ 4.5x10 ⁶
PFH		DPX Series 2 DPX Series 3 SPX Series 3 DPX Series 5 DPX Series Industrial Guardam	2.2x10 ⁴ 1h 9.4x10 ⁴ 1h 2.2x10 ⁴ 1n 2.2x10 ⁴ 1n 2.2x10 ⁴ 1h 2.3x10 ⁴ 1h
) _{es}		SPX Series 2 DPX Series 3 SPX Series 4 SPX Series 5 DPX Series Industrial Guardian	99.2 P/T 44.6 P/T 99.2 P/T 99.2 P/T 99.2 P/T 79.6 P/T
à.,		DPX Series 2 SPX Series 3 DPX Series 4 SPX Series 5 SPX Series Industrial Guardian	77.2 FIT 35.1 FIT 77.2 FIT 77.2 FIT 77.2 FIT 56.5 FIT
λe		DPX Series 2 SPX Series 3 SPX Series 4 DPX Series 5 SPX Series Industrial Guardan	22.0 FIT 9.4 FIT 22.0 FIT 22.0 FIT 22.0 FIT 23.2 FIT
λ		SPX Series 2 SPX Series 3 SPX Series 4 SPX Series 5 SPX Series industrial	22.0 F/T 9.4 F/T 22.0 F/T 22.0 F/T 22.0 F/T 22.0 F/T

Profitability

Material Analysis

Sustainability

Verfication

Auriterin



providing a window into the process

11 APPENDIX 1 - DEFAULT VALUES

Variable	Default Value	Access	Options
Analog Output Alarm Flag	High	RW	High
			Low
			Hold Last
Burst Command Enable	Off	RW	
Burst Option Variable	PV	RW	
Date of Last Factory Calibration	Date of Calibration	RO	
User Selectable Date	Date of Calibration	RW	
Manufacturer Identification Code	0 x 72	RO	
Dev ID (Device Identifier)	Unique number set by Factory	RO	
Final Assembly Number	<blank></blank>	RW	
Local Push-button Enable	Enable	RW	Enabled
			Disabled
Factory Default LRV	0	RO	
Lower Sensor Limit	-0.04 * full scale of SPX 3XXX	RO	
Message Text	HTTP://WWW.DYNISCO.COM/	RW	
PV Minimum Span Value	Factory Default PV_URV divided by 5	RO	
Number of Request Preambles	5	RW	
PV Damping Constant Value	0 Seconds	RW	0-30
PV Lower Range Value	0	RW	0-30
PV Engineering Unit Code	Per Customer Order	RW	0 x 06 – PSI
			0 x 07 – Bar
			0 x 0A – kg/cm ²
			0 x 39 – % of FS
			0 x ED – MPa
PV Upper Range Value	Full scale (same as on label)	RW	
PV Transfer Function Code	Linear	RO	
Rcal Calibration Percentage	80%	RW	20 - 100%
Field Device Serial Number	As Set at Factory	RO	
Тад	?	RW	
Transmit Address	0	RW	0 - 15
Factory Default URV	Per Customer Order	RO	
Upper Sensor Limit	1.5 * full scale of SPX	RO	

rification

Profitability

Material Analysis

Sustainability





fical

Lo Metal

Menu

Profitability

Material Analysis

Sustainability




Material Analysis

Sustainability

13 APPENDIX 3 – Oil Fill Offset

An oil-filled sensor has the advantage of being non-toxic and therefore compliant for many food, medical or other critical applications. A disadvantage of an oil-filled system is that the organic oil fill can degrade over time at high temperatures. Over a period of months and continuously operating at elevated temperatures (>275°C / 525°F), some long chain molecules in the oil can degrade and generate gas molecules. While in continued operation, these gases remain in solution in the oil and have no effect on the performance of the sensor. However, if/when the sensor is returned to room temperature and zero pressure, the gas may come out of the solution (outgas) over a short period of time (minutes to hours), creating a bubble(s) in a closed fill system. At non-operating room temperature and zero pressure, the gas exerts a small additional pressure (on the order of 50-100 psi) and results in an apparent increase in the Zero Output. Therefore, the gas offset error represents a higher percentage effect in lower versus higher pressure range systems. The actual magnitude will depend on the percentage of oil which has degraded over time at temperature.

When the sensor is returned to operation with increased pressure and temperature, the gas bubble(s) will go back into solution. Testing has shown that the gas is typically reabsorbed with temperatures exceeding 100°C / 212°F. With the gas reabsorbed, the sensor is reading the true pressure at specified accuracies. When the sensor is installed and brought to operating temperature and before applying pressure, it can then be re-zeroed without any impact on the calibration accuracy.

Recommended Zero Adjustment

Prior to performing a zero adjustment, it is recommended that the system is installed and the equipment brought to process temperature (<100°C) at or near zero pressure. This will allow any gas to be absorbed into the oil and eliminate offset effects.

If a zero adjustment is conducted at less than 100°C (e.g., bench calibration test port), briefly pressurize to >/=150 psi/10 bar, then depressurize the system prior to performing the zero adjustment. Pressurizing following by depressurizing will temporarily allow any gas to be absorbed into the oil and eliminate offset effects. Verify that the zero output value will be repeated by reapplying pressure to >/ =150 psi/10 bar followed by depressurizing.





Universit

Verfication

Profitability

Material Analysis

1110

Sustainability





fication

Auriterin

Profitability

Material Analysis

Sustainability





Vertication

Auriterin

Profitability

Material Analysis

Sustainability





Universit

Verfication

Profitability

Material Analysis

No.

Sustainability





Verfication

Universit

Profitability

Material Analysis

and a

Sustainability





Verfication

Auriterin

Profitability

Material Analysis

111

Sustainability





Verfication

Auriterin

Profitability

Material Analysis

1111

Sustainability





Universit

Verfication

Profitability

Material Analysis

THE R

Sustainability





Universit

Vertication

Profitability

Material Analysis

Sustainability





erficatio

Auriterin

Profitability

Material Analysis

Sustainability





Vertication

Auriterin

Profitability

Material Analysis

Sustainability





Verfication

Auriterin

Profitability

Material Analysis

1110

Sustainability





Verfication

Auriterin

Profitability

Material Analysis

Sustainability





Verfication

Auriterin

Profitability

Material Analysis

No.

Sustainability





Verfication

Auriterin

Profitability

Material Analysis

1110

Sustainability





Verfication

Auriterin

Profitability

Material Analysis

and a

Sustainability



DYNISCO CONTACT INFORMATION

Please visit our website for up to date contact information:

www.dynisco.com/contact