

1290-1390 Legacy Equipment Cross Reference Table:

Legacy Dynisco 1/8 Din Indicator Model	Current Dynisco 1/8 Din Indicator Model	Alarm Relay Code	Retransmission	24V Transmitter Power	MODbus Comms	Power Supply Option
1290/1390-1-3	1490	4	0	0	0	0
1290/1390-1-1	1490	4	0	0	0	1
1290/1390-2-3	1490	4	1	0	0	0
1290/1390-2-1	1490	4	1	0	0	1
1290/1390-3-3	1490	4	1	0	1	0
1290/1390-3-1	1490	4	1	0	1	1

1291-1391 Legacy Equipment Cross Reference Table:

Legacy Dynisco 1/8 Din Indicator Model	Current Dynisco 1/8 Din Indicator Model	Alarm Relay Code	Retransmission	24V Transmitter Power	MODbus Comms	Power Supply Option
1291/1391-1-3	1490	2	0	1	0	0
1291/1391-1-1	1490	2	0	1	0	1
1291/1391-2-3	1490	2	1	1	0	0
1291/1391-2-1	1490	2	1	1	0	1
1291/1391-3-3	1490	2	0	1	1	0
1291/1391-3-1	1490	2	0	1	1	1
1291/1391-4-3	1490	2	1	1	1	0
1291/1391-4-1	1490	2	1	1	1	1

Dynisco strongly recommends that the end user consult the product specification sheets for both the older and newer replacement instrument, prior to purchase.

These specification sheets can be found on our website:

<https://www.dynisco.com/sensors-and-measurement/instruments>

<https://www.dynisco.com/sensors-and-measurement/legacy-instrumentation-products>